

Contents

| 1. Int | roduction | 2 |
|------------|---|----|
| 1.1 | Product Description | 2 |
| 1.2 | Features | 2 |
| 2. Qu | iick Start | 2 |
| 2.1 | Inventory | |
| 2.2 | Quick Start: Connecting Your Motion Device | 4 |
| 2.3 | Getting Your Target PC Ready | 6 |
| 2.4 | Quick Start: Using the Micronix Motion Controller Platform | 7 |
| 2.5 | Motion With and Without Encoders | 15 |
| 3. Fre | equently Asked Questions | 15 |
| 4. Tro | ouble Shooting | 15 |
| 5. Te | chnical Information | 17 |
| 5.1 | MMC-10 Specifications | 17 |
| 5.2 | Serial Port Setup | 17 |
| 5.3 | RJ11 RS485 Bus | 17 |
| 6. Op | peration | |
| 6.1 | Axis Addressing | |
| 6.2 | Feedback Control | |
| 6.3 | MLN, MLP, and User Defined References | |
| 7. Co | mmands | |
| 7.1 | Command Line Syntax | |
| 7.2 | Command Line Format | |
| 7.3 | Global Commands | |
| 7.4 | Multiple Parameters | |
| 7.5 | Synchronous Move | |
| 7.6 | Internal Programming | |
| 7.7 | | |
| | Terminating Characters | |
| 7.8 | Summary of Commands | |
| 7.8 7.9 | Terminating Characters Summary of Commands Command Descriptions | |



1. Introduction

This document is a quick start guide to be used to get the MMC-10 and accompanying stages connected and functional.

1.1 Product Description

The MMC-10 is a low cost two phase piezo motor controller/driver designed to be used as a standalone single axis unit or interconnected for multi-axis functionality.



- 1. 12V to 36V DC in (24V Nominal, peak current draw 0.5A)
- 2. USB Connector
- 3. Intermodular/RS-485 Input
- 4. Intermodular/RS-485 Output
- 5. Motor/Encoder
- 6. LED Addressing Indicator 2
 - a. Orange Stage is Unaddressed
 - b. Green Stage has an address and is ready
- 7. LED Error Indicator 1
 - a. Red An error has occurred

1.2 Features

- Integrated controller/driver for MICRONIX USA stick-slip piezo motors
- Ultra-compact design
- Open loop/closed loop operation
- Closed loop resolution dependent on the encoder

2. Quick Start



2.1 Inventory

We will begin the setup process by making sure all the components we will need are accounted for. With every MMC-10 controller, the following should be included:



Package Contents:

- 1. MMC-10 Controller
- 2. 24V Power Supply
- 3. Power Cable
- 4. 6' USB Cable
- 5. User Manual
- 6. Supplemental CD
- 7. RJ-11 Daisy Chain Cable (Optional)



2.2 Quick Start: Connecting Your Motion Device.

Now that we have confirmed we have everything we need; we can get the controller and stages set up.

 Connect MMC-10 to Motion Devices: Each stage to be used with an MMC-10 will have a male DSUB15 HD connector attached to it. Plug this into the motor/encoder plug on the MMC-10 unit. This connector will connect the motor to the drive circuitry of the controller, and on closed loop stages will additionally serve to relay the encoder data back to the controller (Pinout available in manual appendix).



2. Connect MMC-10 to Computer: Connect the mini USB connector on the MMC-10 unit to your pc using the included 6' USB cable.





3. (Optional) Connect MMC-10 units together

The MMC-10 has both an in and an out jack for RS-485 communication. This jack also distributes power and is responsible for addressing in situations where

the auto address function is used. Connect the output of one MMC-10 to the input of another to daisy chain multiple MMC-10 controllers together, sharing power and а communication bus (Pinout available in manual appendix). Axes will be addressed in the order they are connected, a "in" unit who's jack is connected to another units "out" jack will have an address one higher than the unit it is daisy chained to, starting with 1.



 Connect MMC-10 to Power Now that everything is connected, power on the device by plugging in the 24V power supply. At this point, the upper LED should be lit green.





2.3 Getting Your Target PC Ready

There are a number of ways to control Micronix controllers, but let's start by setting up the Micronix MCP user interface on your PC.

- 1. Install
 - a. To install the Micronix motion controller platform double click the setup.exe file on the supplied CD or downloaded from http://www.micronixusa.com/motion/support/softwares.cfm and follow the on screen instructions.
 - b. If the on-screen instructions do not take you all the way through the installation process, see the Troubleshooting section on page 15 of this manual.
- **2.** Run
 - a. Open the start menu (Windows 7/Vista) or the Start screen (Windows 8/10)
 - b. Open the 'all programs' tab (Windows 7/Vista) or use the down arrow to navigate to the Apps screen (Windows 8/10)
 - c. Open the Micronix folder (Windows 7/Vista) or navigate to the Micronix section of the Apps screen by scrolling sideways (Windows 8/10)
 - d. Run the Micronix MCP program.





2.4 Quick Start: Using the Micronix Motion Controller Platform

Now that we have connected a stage to a controller, and a controller to a PC, it's time to tie it all together. Your PC should automatically recognize the device plugged into it (your controller) as a com port with the following specs:

By default, Micronix devices will appear as "COM 4". If this comport is already occupied, it will appear as the next available comport. If there is uncertainty about which COM port your Micronix device is occupying, or if you are unable to communicate with your Micronix device via comport, skip to the troubleshooting section on page 15 of this manual for help resolving this issue.

With a com port identified, it is time to connect to the MMC-10 using the Micronix MCP program installed in section 2.2.

| COM4 • COM4 : Open | Close Port Status Byte: |
|-----------------------|--|
| | |
| | Port Control section of Micronix MCP software |
| 1. Port C | Control |
| a | Select the COM port associated with your MMC-10 device COM4 🔹 |
| b. | Click the Open Port button to connect to the MMC-10 Open Port i. This button should change giving you the option to close the port Close Port |
| C. | The Port field should change to indicate the Port is Open. |
| | Port Closed COM4 : Open |
| d. | You will see the progress bar fill and the adjacent field change with information regarding the query process as the program initializes. You are now ready to start moving a stage with your MMC-10. |
| e. | The Axis selector will allow you to switch control between different axes, if multiple axes are being used. |



2. Commands

| Command | Response |
|-------------------------------|---------------------------------------|
| ? Ser | d Terminal Response Information Clear |
| Command List | |
| ACC - Acceleration | |
| AMX - Max Acceleration | |
| ANR - Set Axis Number | |
| CER - Clear Errors | |
| DAT - Dump Trace Data | ≡ |
| DBD - Closed Loop Deadband | |
| DEC - Deceleration | |
| EAD - Set A/D Encoder | |
| ENC - Set Encoder Resolution | |
| END - End Program Recording | |
| EPL - Encoder Polarity | |
| ERA - Erase Program | |
| ERR - Read and Clear Errors | |
| EST - Emergency Stop | |
| EXC - Execute Program | |
| FBK - Set Open or Closed Loop | |
| HOM - Home | |
| JAC - Jog Accel and Decel | |
| JOG - Jog Mode | v l |

Terminal section of Micronix MCP software

a. **Command** – This field allows you to interface with your MMC-10 through manual terminal commands. For more about Commands see section 7 of the reference



Manual.

- i. Enter your command in the blank field
- ii. This button appends a '?' on the end <u>of the</u> command making it a read function
- iii. Send This button sends the command to the MMC-10
- b. **Command List** This is a list of commands available to the MMC-10. Clicking any list item will send the 3 character command to the Command box with the preceding axis number.

Command List ACC - Acceleration AMX - Max Acceleration ANR - Set Axis Number CER - Clear Errors DAT - Dump Trace Data DBD - Closed Loop Deadband DEC - Deceleration EAD - Set A/D Encoder ENC - Set Encoder Resolution END - End Program Recording EPL - Encoder Polarity ERA - Erase Program ERR - Read and Clear Errors EST - Emergency Stop EXC - Execute Program FBK - Set Open or Closed Loop HOM - Home JAC - Jog Accel and Decel JOG - Jog Mode



c. Response

i. Terminal – This field shows the responses from the MMC-10.1. The clear button will delete all entries in the Terminal

| | | Resp | onse | | |
|----------|----------|-------------|------|-------|---|
| Terminal | Response | Information | | Clear | н |
| | | | | | 1 |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | 1 |
| | | | | | |

- ii. Response Responses to user queries are displayed here.
 - 1. The clear button will delete all entries in the Response terminal.



iii. Information - This field will show some information about the selected command from the command list along with an example





3. Motion – This section allows you to control movement with an easy to use user interface

Motion section of Micronix MCP software

a. Position

- i. Zero This button will set the current position to zero for both the calculated and encoder reading.
- ii. Calc This is the calculated position based on the number of steps taken (value in millimeters)
- iii. Enc This is the position as read by the encoder assuming one is attached (value in millimeters). If no encoder is attached, this value reads 0.000000.

| | Position | |
|------|----------|----|
| Calc | 0.000000 | mm |
| Enc | 0.000000 | mm |
| | Zero | |

- b. **Motion** This section allows you to control the movement of a stage attached to your MMC-10
 - i. Target Pos 1 This field shows the target for an absolute move that will be executed upon pressing the adjacent 'GO' button
- Target Pos 1

 0.000000
 mm
 GO
 Target Pos 2
 0.000000
 mm
 GO
 Increment
 0.000000
 mm
 SO
 Mm
 Mm
 SO
 Mm
 SO
 Mm
 Mm

Motion

- ii. Target Pos 2 This field shows the target for an absolute move that will be executed upon pressing the adjacent 'GO' button
- **iii. Increment** This field indicates the amount of displacement a relative move will travel upon pressing one of the adjacent '<','>' buttons.
- iv. STOP This button will execute an Emergency Stop Command.



- c. **Motion Parameters** This section dictates some parameters for how a movement function is executed.
 - i. Vel This field indicates the controllers current set velocity
 - **ii.** Accel This field indicates the controllers current set value for acceleration
 - iii. **Decel** This field indicates the controllers current set value for deceleration
- d. Test
 - i. Max Position Set this value to the desired upper limit of travel
 - ii. Min Position Set this value to the desired lower limit of travel
 - iii. Random If set the controller will send random movements. If left unset, the stage will run from the Max Position to the Min Position as defined above.
 - iv. START This will either execute the random movements between limits or the limit to limit run.
 - v. **Position** This column is the start position for the move that is occurring.
 - vi. **Dest** This column is the destination position for the move that is currently occurring.
 - vii. **Time** This column indicates the time at which each move occurred.

| Vel | 2.000 | 🛃 mm/s |
|-------|-----------|---------|
| Accel | - 100.000 | ➡ mm/s² |
| Decel | - 100.000 | + mm/s² |

| | Test - Cou | int: 0 |
|--------------|------------|--------------|
| Position | Dest | Time |
| | | |
| | | |
| | | |
| | | |
| | | |
| Min Position | N | lax Position |
| 1.000 | 🕂 mm 🔒 | 1.000 💽 mm |
| Random | | START |
| | | |



4. System

| Sminands Motion | System | | | | | | |
|------------------------------------|----------------|------|------------------|------------|-------------------|----------------------------|--------------|
| Ax | es | | | Parameters | | Encoder Polarity | |
| ⊿ MMC | | | Max Velocity | 2.560 | mm/s | 🔘 Default | Reverse |
| MMC-100 - 4 | Axis: 1 | | Max Acceleration | 500 | mm/s ² | Motor | Polarity |
| MMC-100 - A | Axis: 2 | | | | | 🔘 Default | Reverse |
| MIMC-100 - A | 4XIS: 5 | | Jog Acceleration | 250 | 📑 mm/s* | Dicola | w Units |
| | | _ | + Travel Limit | - 999 | 🛃 mm | Linear | Angular |
| Axis 1 : Startu | p Parameters | | - Travel Limit | 999 | 🛃 mm | Avia | Due On Start |
| Name | Value | * | Step Resolution | - 8000 | steps/um | | |
| Firmware Version | MMC-100.X3v1.4 | | Enc Resolution | 0.02 | + um/cnt | | |
| Acceleration | 100 mm/s² | Ξ | | 0.02 | ani, chi | Co | ntrol |
| Max Acceleration | 500 mm/s² | | | Errors | | Loop Open | Loop 🔻 |
| Deceleration | 100 mm/s² | | | | | Deadband | 1 I cot |
| DeadBand Count | 1 steps | | | | | | |
| DeadBand Timeout | 0 sec | | | | | Time Out 🕒 | 0 📑 sec |
| Encoder Resolution | 0.02 um/cnt | | | | | PID Pa | rameters |
| Encoder Polarity Motor Polarity | Reverse Mode | _ | | | | | |
| mozor Polarity | Neverse wode | | | | | кр 📋 0.50 | U 🗎 |
| Store Parameters | Firmware | | | | | Ki 🕘 0.00 | 0 🛃 |
| Save | MMC-100.X3v1 | .4.5 | Clear | | Request | Kd 📘 0.00 | 0 |

System section of Micronix MCP software

- **b. Axes** This field will show the stages attached to the program along with associated axis number
- **c. Parameters** Upon opening the port as discussed above, the MMC-10 MCP will populate the following fields.
 - i. Max Velocity Maximum allowed Velocity
 - ii. Max Acceleration Maximum
 - Allowed Acceleration
 - iii. Jog Acceleration Setting for Jog Acceleration
 - iv. Travel Limit The soft travel limit in the negative direction. The controller will not allow the stage to be moved outside this limit
 - **v. + Travel Limit** The soft travel limit in the positive direction. The controller will not allow the stage to be moved outside this limit
 - vi. Step Resolution Steps per micron resolution
 - vii. Enc Resolution Microns per encoder count





Axes MMC MMC-100 - Axis: 1 MMC-100 - Axis: 2 MMC-100 - Axis: 3

- d. Encoder Polarity This setting allows the user to flip positive and negative directions for the Encoder.
- e. Motor Polarity This setting allows the user to flip positive and negative directions for the Motor.
- f. Display Units This setting allows switching between linear units (mm) and rotary units (degrees).
- g. Axis This is a special command that needs to be unlocked in the settings menu (Settings Menu -> Advanced Tab -> Unlock Axis Select). This field is associated with the ANR command and allows you to reset the axis number for the current selected axis.
- h. Run On Start Here you can select which program you would like the stage to execute upon start up. For more on internal programs, see page 20 of this manual.
- i. Control This frame allows you to change options regarding feedback control
 - i. Loop Here you can choose between 4 different modes of control
 - 1. Open Loop This mode does not take encoder position into account.
 - 2. Clean Open Loop This mode also does not take encoder position into account but maintains a consistent pitch.
 - Open Loop Close deceleration This operation will run in clean open loop mode and then read from the encoder to correct its position at the end of travel (Not a constant velocity move).



4. Close Loop – This mode will constantly poll the encoder and make corrections to achieve the target trajectory (Constant velocity).



Encoder Polarity

Default
Reverse

Motor Polarity

Default
Reverse

Display Units

Linear
Angular

Axis

Run On Start

0

- ii. Deadband This setting changes the amount of error the closed loop control mode will allow before trying to reposition.
- iii. Time Out This setting allows you to change the amount of time a closed loop operation will search until it times out.
- j. Startup Parameters This field will populate with the saved startup information for the selected axis
- k. Error
 - i. Clear This button will clear all error codes
 - ii. Request This button will dump all error codes to the above terminal

- I. PID Parameters this field allows you to change the parameters for closed loop operation
 - i. Kp Proportional Gain
 - ii. Ki Integral Gain
 - iii. Kd Differential Gain
- **m.** Store Parameters This will allow you to save the settings you have entered as a file. This will allow you to restore these parameters in the future if necessary.
- **n.** Firmware This Field indicates the Firmware version installed in the MMC-10 controller











2.5 Motion With and Without Encoders

Open Loop

If you have an open loop system (No Encoder), after opening the port from part 2.3-1 you can test movement by entering a value in the increment field and press either of the buttons. Be sure that the value is within the confines of the travel limits. The stage should move and you should see the Calc field change.

Closed Loop

If you have a closed loop system (Attached Encoder), after opening the port from part 2.3-1, ensure that the controller is in closed loop on the system page (section 2.3-4h.). Then in the motion section enter a value in the increment field and

press either of the buttons. Be sure that the value is within the confines of the travel limits. The stage should move and you should see the Calc and Enc fields change and end at the same value.

3. Frequently Asked Questions

Why is my stage continuously running in one direction when set to closed loop (nFBK2, nFBK3)? Most likely your encoder polarity is backwards. Use the nEPL? command to query the current setting and then if it is 1 send nEPL0 if it is 0 send nEPL1.

How do I get my settings like velocity, acceleration, and limits to remain when I power down the controller?

Use the nSAV command. This command writes all current settings to non-volatile RAM which will allow them to persist between power cycles. If you would like to revert to the factory settings simply use the nDEF command to revert the controller to its default parameters. (Note: to have these persist between power cycles don't forget to run the nSAV command)

What do the red and green LEDs mean?

The top LED is an address indicator. At startup it will flash from Red (unaddressed) to orange (currently being addressed) to Green (addressed and ready for commands). The bottom LED is an error indicator. When an error occurs, the LED will illuminate red. Use the nERR? command to read all errors. By default, this LED will be off.

Why are the responses to my query commands coming back with garbage characters?

The communication bus for the MMC-10 is half-duplexed. It is important to ensure that you do not send commands when there are responses coming back from the MMC-10. Also, please ensure that the end of line character is a r. If you sent r n a response will be sent at the same time as the n is on the bus and will cause bus contention.

4. Trouble Shooting

Difficulty Installing the Micronix Motion Control Platform

To run the Micronix MCP software, you will need the .NET Framework 4.0 or higher to already be installed on the target computer. If the target computer has Windows 7 or later installed and is current on all updates, .NET 4.0 should already be installed. If the target computer does not have .NET 4.0 or you are unsure if the target computer has the .NET Framework 4.0, follow these steps:



- a. Navigate to the support section of the Micronix Website at http://www.micronixusa.com/motion/support/softwares.cfm
- b. Download the file labeled DOT_NET Installation.
- c. Run the application and follow the on screen instructions.
- d. Return to section 2.2 and follow instructions. If you are still encountering problems, contact Micronix support.

My MMC-10 is not being recognized as a com port by my system.

In some cases, due to a variety of factors, controllers will not be recognized as Com ports. Here are steps to take to resolve this issue.

1. Make sure the device is powered on and the top LED is lit green. If the top LED is not lit green, or if power is connected but no LEDs are lit, contact Micronix support.

2. Make sure the USB port the controller is plugged in to is functional. Try to plug the MMC-10 into another USB port, or if using a USB hub try plugging the unit directly into the PC USB port. Try another device like a thumb drive in the USB port and make sure it connects.

3. If the controller is powered on and plugged in to a functional USB port, but is still not being recognized, try installing the Com Port drivers located at

http://www.micronixusa.com/motion/support/softwares.cfm

and restarting your computer. If this does not solve the problem, please contact Micronix Support.

4. If the com port is recognized, but the Micronix Motion Control Platform is unable to communicate with it, double check the setting of the port. To do this, open the control panel in Microsoft windows and navigate to the device manager. Locate the com port associated with the MMC unit (if there are multiple com ports open, unplug and replug the unit and look for the com port that responds). Right click the com port associated with the MMC unit and select "Properties" from the menu that appears. On the "Port Settings" tab, make sure the following values are set.

| Software Parameter | Setting |
|--------------------|---------|
| Baud Rate | 38400 |
| Data Bits | 8 |
| Stop Bits | 1 |
| Parity | No |
| Handshake | No |

Difficulty Identifying the Correct Com Port

In some cases, in which a large number of com ports are being used or com ports are tied up by the system, it may be difficult to identify which com port is associated with which device. The Micronix MCP programs drop down menu will display the most recently connected com port on the bottom of the list. As such, an easy way to identify a device is to power cycle it, it should now be the last listed com port.



5. Technical Information

5.1 MMC-10 Specifications

| Parameter | Description |
|-----------------|------------------------------|
| Motor Type | Stick-slip piezo motors |
| Interface | USB 2.0 compliant/RS-485 |
| Commands | ASCII Commands |
| Trajectory Mode | Trapezoidal velocity profile |
| Servo Clock | 10 kHz |

* Each axis requires 0.5A at peak usage. A up the individual axis power requirements to determine the power supply amperage requirement.

5.2 Serial Port Setup

Below are the virtual RS-232 configuration settings necessary for correct communication setup:

| Software Parameter | Setting |
|--------------------|---------|
| Data Bits | 8 |
| Stop Bits | 1 |
| Parity | No |
| Handshake | No |
| Baud rate | 38400 |
| | |

5.3 RJ11 RS485 Bus

The RS485 Intermodular RJ11 connector connects directly to the same Serial bus as the FTDI interface above. In addition to being an RS-485 line, this connector also distributes power and is responsible for addressing in situations where the auto address function is being used. MMC-10 units can be connected in a daisy chain fashion, with the RS-485 Out of one unit plugging in to the RS-485 In of the next unit as shown in section 2.3 of this manual. When daisy chaining, keep in mind that each unit has a peak current draw of 0.5A, so the number of daisy chained units is limited by the current rating of the power supply being used.



6. Operation

6.1 Axis Addressing

Auto Addressing is the default method of assigning axis numbers on start up. Controllers are automatically assigned axis numbers on every power up, starting with axis 1 and increasing consecutively until reaching axis 99.

Manual axis numbers may be assigned to a unique controller using the ANR Command. This overrides Auto Addressing, as the controller stores the axis number until reassigned or reset back to Auto Addressing. In the case of having a mix of manually assigned and auto addressed controllers, the Auto Addressed axis numbers increase consecutively after each manually assigned axis in the stack. For example; in a stack of 5 controllers with the third controller manually assigned to axis 10, the axis numbers will read: 1, 2, 10, 11, 12

If two controllers are accidentally assigned the same axis number, use a global command to reset all controllers back to Auto Addressing.

6.2 Feedback Control

The MMC-10 has four different movement modes of operation. When executing a move command, the controller will drive a stage differently when set to different modes. The FBK command is used to switch between these modes.

The first mode (nFBK0) is a traditional Open Loop. It follows a standard trapezoidal velocity characteristic. It bases the transition between acceleration, constant velocity and deceleration on the resolution settings (nREZx) or the distance it travels in one pulse. This is entirely theoretical and does not guarantee a set trajectory or end point.

The second mode (nFBK1) is also open loop, however this one does not follow the standard trapezoidal velocity set by the user. Instead, it rounds off the velocity to an even number of servo clocks per transition. This causes the motor to sound much cleaner than the previous mode. However, it does sacrifice accuracy.

The third mode (nFBK2) is a version of closed loop; meaning it takes position data from an attached encoder and uses it to ensure that it stops at the desired position. In this mode the controller runs in the second open loop mode (nFBK1) until it reaches the deceleration point. At this point it constantly reads from encoder and corrects its position to arrive at the correct position. This, unlike the first two modes can guarantee position within the specified deadband (DBN Command). However, this mode cannot guarantee a known trajectory.

The fourth mode (nFBK3) is a more traditional closed loop. The controller will constantly try to achieve an ideal trapezoidal velocity characteristic. Like the previous mode it too can guarantee position final within the specified deadband.



6.3 MLN, MLP, and User Defined References

The move to limit negative (MLN) and moves to limit positive (MLP) commands both require the attached stage to have an encoder and will move the stage to end of travel in their respective directions. The orientation of positive versus negative limits can be changed using the limit direction (LDR) command. In addition, a user created reference point can be created by moving to a limit, moving out of said limit the desired amount, and then using the zero (ZRO) command to set both the calculated and encoder positions to the value 0.000000mm. To return to this reference point, the user need only use the move to absolute (MVA) command and move to the location 0.000000mm. See Programming Example 3 of the Internal Programming section of this manual (Page 91) for detailed instructions on creating a routine that runs on startup and automatically creates this reference point.

7. Commands

7.1 Command Line Syntax



There are three components to every command prompt. The first is the "<u>Axis</u> <u>Number</u>" which designates which controller, or axis, will receive the command. If the "Axis Number" is 0, then the command will be sent globally to all connected controllers. It is possible to connect up to 99 controllers; therefore the "Axis Number" will be an integer value from 0 through 99.

The second component is the "<u>Command</u>", which is always comprised of three letters. Each command is outlined, along with its corresponding parameters, in the *Command Description* section 5.9 of this manual.

The third and final component is the "<u>Parameter</u>". This portion is command dependent, meaning that the parameter value will change depending on the specific requirements of the "Command". Where applicable, a question mark (?) may be substituted to initiate a read operation which will return information regarding the particular command. There may be up to three separate parameters for a particular command, each parameter value is separated by a comma (,).

All white space (blank spaces) are ignored in the command format. The following are examples of equivalent commands:

4TRM13,45 4 TRM 13, 45



7.2 Command Line Format

Commands are first executed in the order that they are input, then line by line. This means that two commands on the same line are executed significantly closer to each other than if they were on two separate lines. Each command is separated by a semicolon (;) and every command line ends in a terminator (EX: carriage return). The following is an example of a command line entry:

1MVR16;3MVR12 | Axis 1, Move 16 mm [16 degrees]; Axis 3, Move 12 mm [12 degrees]

Using multiple commands on the same command line allows for synchronization of different commands to different axes. Up to 8 commands are allowed per command line.

Only one read operation is allowed per line. The controller will not send information unless requested to do so by a read operation.

7.3 Global Commands

Some commands have the option of being called globally. This means that you can send the same command to all available axes. To do this, replace the axis number of a global command with a '0'. For example; 0ACC 50 will set the acceleration of all available axes to 50 mm/s² [degrees/s²].

7.4 Multiple Parameters

When dealing with a command that has multiple parameters, it is possible to change a single parameter by omitting numbers for the parameters that will remain unchanged. For example; 4PID,,3 will only change the third parameter to a new value, "3".

7.5 Synchronous Move

It is possible to execute multiple motions at the same time by setting up and executing a synchronous move. To set up a synchronous move, use the MSA and MSR commands. These commands can be written on the same command line (up to 8 allowed) or on separate lines followed by a line terminator. To execute the move, use the RUN command on the proceeding command line followed by a line terminator. For example;

1MSA4;2MSA4;3MSA4 | Axis 1, Move 4mm; Axis 2, Move 4mm; Axis 3 Move 4mm ORUN | Run Synchronous Move

Or

1MSA4| Axis 1, Move 4mm2MSA4| Axis 2, Move 4mm3MSA4| Axis 3 Move 4mmORUN| Run Synchronous Move



7.6 Internal Programming

A program may be used to save time when repeatedly using a sequence of commands. Each controller or axis must be programmed individually; however, multiple controllers may execute the same program at the same time. For a more detailed look at the internal programming features of the MMC-10, see the appendix of this manual.

7.7 Terminating Characters

When communicating with the controller, it is necessary to note the terminating characters involved in transmitting and receiving data. To send data to the controller, enter the desired commands in the command line followed by the new line and carriage return terminating characters $[\n\r]$, or just the carriage return terminating character [$\n\r]$, or just the carriage return terminating character [$\n\r]$, and the final line will be followed by the new line terminating character [$\n\r]$, and the final line will end in the new line and carriage return terminating characters [$\n\r]$. The Hexadecimal value for new line [$\n\$] is 0X0A and for carriage return [$\r]$] is 0X0D. The following is an example of data transmission:

1VEL0.005 \n\r | Axis 1, Set velocity to .005 mm/s [degrees/s²] [New line, Carriage Return]



| 7.8 S | Summary of Commands |
|-------|---------------------|
|-------|---------------------|

| Command | Description | Du M | uring otion | Rea | l-time | Program | | Global | | Page |
|---------|-----------------------------------|--------------|----------------|--------------|--------------|--------------|------|--------------|------|------|
| | - | Set | Read | Set | Read | Set | Read | Set | Read | |
| ACC | Acceleration | | √ | √ | √ | \checkmark | | √ | | 16 |
| AMX | Maximum Allowable Acceleration | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 17 |
| ANR | Set Axis Number | | \checkmark | \checkmark | \checkmark | | | √* | | 18 |
| CER | Clear Errors | | | \checkmark | | | | \checkmark | | 19 |
| DAT | Dump Trace Data | | | | \checkmark | | | | | 20 |
| DBD | Closed Loop Deadband | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 21 |
| DEC | Deceleration | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 22 |
| DEF | Restore Factory Defaults | | | \checkmark | | | | | | 23 |
| EAD | Set Analog or Digital Encoder | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 24 |
| ENC | Select Encoder Resolution | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 25 |
| END | End Program Recording | | | \checkmark | | \checkmark | | | | 26 |
| EPL | Encoder Polarity | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 27 |
| ERA | Erase Program | | | \checkmark | | | | | | 28 |
| ERR | Read and Clear Errors | | \checkmark | | \checkmark | | | | | 29 |
| EST | Emergency Stop | \checkmark | | \checkmark | | \checkmark | | \checkmark | | 30 |
| EXC | Execute Program | | | \checkmark | | | | \checkmark | | 31 |
| FBK | Set Open or Closed Loop Mode | | \checkmark | \checkmark | \checkmark | | | | | 32 |
| FMR | Upload Firmware | | | \checkmark | | | | | | 33 |
| HCG | Home Configuration | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 34 |
| HOM | Home | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 35 |
| IOD | IO Pin Definition | | | \checkmark | | | | | | 36 |
| IOF | IO Function | | | \checkmark | | | | | | 37 |
| JAC | Jog Acceleration and Deceleration | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 38 |
| JOG | Jog Mode | \checkmark | | \checkmark | | | | | | 39 |
| LDR | Limit Switch Direction | | | \checkmark | | | | | | 40 |
| LCG | Limit Configuration | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 41 |
| LIM | Limit Status | | \checkmark | | \checkmark | | | | | 42 |
| LST | Program List | | | \checkmark | | | | | | 43 |
| LPL | Limit Switch Polarity | | \checkmark | \checkmark | \checkmark | | | | | 44 |
| MLN | Move to Negative Limit | | | \checkmark | | \checkmark | | \checkmark | | 45 |
| MLP | Move to Positive Limit | | | \checkmark | | \checkmark | | \checkmark | | 46 |
| MOT | Toggle Motor On/Off | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 47 |
| MPI | Motor Polarity | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 48 |
| MSA | Synchronous Move – Absolute | | | ~ | | | | ~ | | 40 |
| MSA | Synchronous Move Palativa | | | , , | | | | , , | | 50 |
| MVA | Move Absolute | | | • | | 1 | | • | | 51 |
| MVD | Move Polative | | | • - | | • - | | • | | 52 |
| | | | ./ | • | ./ | v | | • | | 52 |
| POL | Loop Program | | v | v | v | | | v | | 55 |
| PGM | begin Program Recording | | v | v | v | | | | | 54 |



| Command | Description | Dı Me | During Motion Real-time | | l-time | Program | | Global | | Page |
|---------|------------------------------|--------------|----------------------------|--------------|--------------|--------------|------|--------------|------|------|
| | | Set | Read | Set | Read | Set | Read | Set | Read | |
| PGS | Run Program At Start-Up | | | \checkmark | \checkmark | | | \checkmark | | 55 |
| PID | Set Feedback Constants | | \checkmark | \checkmark | \checkmark | | | | | 56 |
| POS | Position | | \checkmark | | \checkmark | | | | | 57 |
| REZ | Set Resolution | | \checkmark | \checkmark | \checkmark | | | \checkmark | | 58 |
| RST | Perform Soft Reset | | | \checkmark | | | | \checkmark | | 59 |
| RUN | Start Synchronous move | | | \checkmark | | | | \checkmark | | 60 |
| SAV | Save Axis Settings | | | \checkmark | | | | \checkmark | | 61 |
| STA | Status Byte | | \checkmark | | \checkmark | | | | | 62 |
| STP | Stop Motion | \checkmark | | \checkmark | | \checkmark | | \checkmark | | 63 |
| SVP | Save Startup Position | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 64 |
| SYN | Sync | | | | | \checkmark | | \checkmark | | 65 |
| TLN | Negative Soft Limit Position | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 66 |
| TLP | Positive Soft Limit Position | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 67 |
| TRA | Perform Trace | | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 68 |
| VEL | Velocity | \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | 69 |
| VER | Firmware Version | | \checkmark | | \checkmark | | | | | 70 |
| VMX | Max. Allowable Velocity | | \checkmark | | \checkmark | | | | | 71 |
| VRT | Encoder Velocity | | \checkmark | | \checkmark | | | | | 72 |
| WST | Wait For Stop | | | | | \checkmark | | | | 73 |
| WSY | Wait For Sync | | | | | \checkmark | | \checkmark | | 74 |
| WTM | Wait For Time Period | | | | | \checkmark | | | | 75 |
| ZRO | Zero Position | | | \checkmark | | \checkmark | | \checkmark | | 76 |
| ZZZ | Take Axis Offline | | | \checkmark | | | | \checkmark | | 77 |

* see ANR command page 18 for more info



7.9 Command Descriptions



Acceleration

| During | Motion | Real | l-time | Prog | ram | Glo | obal | | | | |
|---|---|--|--|---------------------------|---------------------------|--------------|------------------|--|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | | |
| | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | | | | |
| Command Descript | ł ion: | This command is used to set the desired acceleration for the specified axis, distinct from the deceleration [DEC]. The acceleration value must be less than the maximum acceleration [AMX] for the command to be accepted. | | | | | | | | | |
| Returns: | eturns: A read operation returns the acceleration value in mm/s^2 for the specified axis. | | | | | | | | | | |
| nACCx – Standard syntax nACC? – Read acceleration value 0ACCx – All axes set acceleration value Syntax: Error [#]: ACC? – Read operation with missing axis number [27] nACC – Missing acceleration parameter [28] | | | | | | | 7] | | | | |
| Parameter Descript | r ion: | n[int] - x[float] - ? - | Axis number Acceleration Read acceleration | ation value | | | | | | | |
| Parameter Range: | r | n - 0 to 99 x - 000.00 | 9 01 to AMX (50 | 0.000 mm/s ² [| degrees/s ²]) | | | | | | |
| Related Command | ds: | DEC, VEL, JAC, AMX | | | | | | | | | |
| Example: 4ACC? Axis 3, Set acceleration to 0.25mm/s ² - 4ACC? Axis 4, Read acceleration v | | | | | | | s ²] | | | | |





Maximum Allowable Acceleration

| During | Motion | Rea | l-time | Prog | ram | Glo | obal | | | |
|---------------------|--|-------------------------|---|---|----------------------|--------------------------|------------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | | |
| Comman Descrip | d tion: | This co acceler | mmand is u ation for the | used to set to set to specified | the maxim axis. | um allował | ole | | | |
| Returns: | | A read acceleration | operation re ation value | eturns the r in mm/s ² fo | naximum a | allowable ified axis. | | | | |
| Syntax: | nAMXx – Standard syntax nAMX? – Read maximum allowable acceleration value 0AMXx – All axes set maximum allowable acceleration value x: Error [#]: AMX? – Read operation with missing axis number [27] nAMX – Missing maximum acceleration parameter [28] | | | | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] ? | — Ax — Maximum a — Read maxin | kis number acceleration num allowable | e acceleration | value | | | | |
| Paramete Range: | r | n - 0 to x - 000 | o 99).001 to 500.00 | 0 mm/s² [degr | ees/s ²] | | | | | |
| Related Comman | ds: | DEC, V | EL, JAC, V | VMX, ACO | 2 | | | | | |
| Example | : | 2AMX1 - | 2AMX1.500 Axis 2, Set max acceleration to 1.500 mm/s ² [degrees/s ²] | | | | | | | |
| | | OAMX ? | | | AX18 6, Read | max accelerat | tion value | | | |





Set Axis Number

| During | Motion | Rea | l-time | Prog | gram | Gl | obal | | |
|---------------------|---|--|---|---|--|--|----------------------------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | √* | | | |
| Comman Descrip | d tion: | manually assigning an axis number to a controller. Auto Addressing is the default method of assigning axis numbers on power up and may be reassigned to an axis by substituting a "0" for the parameter value. Simultaneous axis swapping is possible by using multiple ANR command on the same command line. A save [SAV] followed by a controller reset [RST] is required for changes to take effect. If wo or more axes in the same stack have the same address bus contention will occur causing invalid controller response and erratic behavior (including inaccessible axes). To correct this, issue the commands 0ANR0, then 0SAV, followed by 0RST to restore default auto addressing. * This command can be called globally by specifying a '0' for the axis number; however it will only work if the new axis number parameter is set to '0' for auto-addressing. | | | | | | | |
| Returns: | A read operation returns the following axis number values for the specified axis: 0 - Auto Addressing assigned (default) 1-99 - Manually assigned, axis number displayed | | | | | | | | |
| Syntax: | | nANR2 nANR4 Error [ə | x — Sta ? – Read axis n #]: ANR? nANR – Mi ANRx – Mi | andard syntax number value — Read o issing new axis issing axis nur | operation with 1 s number parar nber [30] | nissing axis n neter [28] | umber [27] | | |
| Paramete Descrip | r tion: | n[int] - x[int] - ? - | - Axis number - New axis num - Read axis num | iber, 0 for Aut mber value | o Addressing | | | | |
| Paramete Range: | r | n - 0 to x - 0 to | 99 99 | | | | | | |
| Related Comman | ds: | RST | | | | | | | |
| Example | : | 5ANR1 Set to axi – 4ANRC However | ; 1ANR5 s 1; it will | remain axi | Simultaneous Axis 1, Set to Axis 4 Set to is 4 until the M | s axis swappin to axis 5 Auto Address MC-100 is res | g: Axis 5, sing. set | | |





Clear Errors

| During | Motion | Rea | l-time | Pro | gram | Global | | | | |
|--|-------------|--|--|--------|-------------------|--------------|---------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | \checkmark | | | | \checkmark | | | | |
| Command Description:This command is used to clear all error messages without reading them. | | | | | | | without | | | |
| Returns: | | A read | A read operation cannot be used with this command. | | | | | | | |
| Syntax: | | nCER – Standard syntax OCER – All axes clear error messages | | | | | | | | |
| Paramete Descrip | er tion: | n[int] | — Axis number | | | | | | | |
| Paramete Range: | er | n = 0 to | 99 | | | | | | | |
| Related Comman | ds: | ERR | | | | | | | | |
| 1CER Axis 1, clear error messages | | | | | | | | | | |
| Example | : | _ | | | | | | | | |
| 1 | | OCER | | All ax | es, clear error 1 | nessages | | | | |



(DAT)

Dump Trace Data

| During | Motion | Rea | -time | Pro | gram | Global | | | | |
|---|-------------|--|-------------------------------|-----------|-----------------|--------|------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | | \checkmark | | | | | | | |
| Command Description: This command is used to read trace data from a specified axis initially recorded by the trace command [TRA]. The retrieved trace data set is dumped from the controller, consequently allowing the data to be retrieved only once | | | | | | | | | | |
| Returns: | | A read operation returns the trace data values for the specified axis in the following format: [Theoretical Position (Encoder Counts)],[Actual Position(Encoder Counts)], [DAC Value], [Not Used] | | | | | | | | |
| Syntax: | | nDAT? – Read trace data values Error [#]: DAT? – Read operation with missing axis number [27] nDAT – Missing read operation parameter [28] | | | | | | | | |
| Paramete Descrip | er tion: | n[int] – ? – | Axis number Read trace dat | ta values | | | | | | |
| Paramete Range: | r | n-1 to 9 | 99 | | | | | | | |
| Related Comman | ds: | TRA | TRA | | | | | | | |
| Example | : | 11DAT | ? | Axis 11, | Read trace data | values | | | | |



(DBD)

Closed Loop Deadband

| During | Motion | Rea | l-time | Prog | gram | Glo | obal | | | |
|---------------------|--------------|---|--|---|---|--|-------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | | |
| Comman Descrip | d tion: | deadband timeout values. Deadband refers to the number of encoder counts (±) from the target that is considered acceptable. If the parameter (x1) is set to "0", the controller will continuously oscillate around the target. Deadband timeout refers to the amount of time that the controller will try to move into the deadband area. If the parameter (x2) is set to "0", the controller will seek continuously. | | | | | | | | |
| Returns: | | A read operation returns the deadband and deadband timeout values for the specified axis. | | | | | | | | |
| Syntax: | | nDBDx1,x2 – Standard syntax nDBD? – Read deadband and deadband timeout values 0DBDx1,x2 – All axes set deadband and deadband timeout values Error [#]: DBD? – Read operation with missing axis number [27] nDBD – Missing deadband and deadband timeout parameter values [28] | | | | | | | | |
| Paramete Descrip | er tion: | n[int] x1[int] x2[floa ? | Axis nur Deadbar Deadbar Read dea | nber nd d timeout adband and dea | adband timeou | it values | | | | |
| Paramete Range: | er | $egin{array}{ccc} n & -0 \ t \ x1 & - \ { m En} \ x2 & - \ { m En} \end{array}$ | o 99 coder depende coder depende | nt, 0 for contin nt, 0 for infinit | uous, Encode te, Seconds (d | r Counts efault 0) | | | | |
| Related Comman | ds: | ENC, E | PL | | | | | | | |
| Example | : | 1DBD1 - 4DBD5 | 0,1 ,0 | Axis 1, 5 & deadb Axis 4, 5 deadband | Set deadband t and timeout to Set deadband t d timeout to in | to 10 encoder o o 1 second to 5 encoder co offinite | ounts | | | |



DEC

| Decelerat | Deceleration | | | | | | | | | | |
|--|---|-------------------------|--|---------------------------|--|---------------------------|-----------------------------------|--|--|--|--|
| During | Motion | Rea | -time | Prog | ram | Glo | obal | | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | | |
| | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | | | | |
| CommandThis command is used to set the desired decelerationCommandspecified axis, distinct from the acceleration [ACDescription:deceleration value must be less than the maximum acceleration value [AMX] for the command to be | | | | | | | on for the]. The accepted. | | | | |
| Returns: A read operation returns the deceleration value in mm/s^2 the specified axis. | | | | | | | nm/s ² for | | | | |
| Syntax: | nDECx – Standard syntax nDEC? – Read deceleration value 0DECn – All axes set deceleration value Syntax: Error [#]: DEC? – Read operation with missing axis number [27] nDEC – Missing deceleration parameter [28] | | | | | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] ? | Axis numb Deceleration Read decent | er n leration value | | | | | | | |
| Paramete Range: | r | n = 0 to x = 000 | 99 .001 to AMX (| 500.000 mm/s | ²) [degrees/s ²] | | | | | | |
| Related Comman | ds: | ACC, A | MX, VEL | | | | | | | | |
| Example | : | 2DEC1 - | .25 Axis | s 2, Set deceler | ration to 1.25 | mm/s ² [degree | s/s ²] | | | | |
| | | 7DEC? | | Axis 7, I | Read decelerat | tion value | | | | | |



DEF

Restore Factory Defaults

| During | Motion | Rea | l-time | Prog | ram | Global | | | |
|--|--|--|-------------|-------------------|----------------|--------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | \checkmark | | | | | | | |
| Command Description: This command restores the factory default parameters. | | | | | | | ers. | | |
| Returns: | | A read operation is not available with this command. | | | | | | | |
| Syntax: | nDEF — Standard syntax ntax: Error [#]: | | | | | | | | |
| | | | DEF – M | issing axis nun | nber [30] | | | | |
| Paramete Descrip | r tion: | n[int] | — Axis numb | er | | | | | |
| Paramete Range: | r | n - 1 to | 99 | | | | | | |
| Related Comman | ds: | SAV | | | | | | | |
| Example | : | 1DEF | Axis | s 1, set all defa | ult parameters | 3 | | | |



(EAD)

Set Analog or Digital Encoder

| During | Motion | Rea | -time | Prog | ram | Glo | obal | | |
|---------------------|---|---|---|--------------------------|---------------------------|------------------|------------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | |
| Comman Descrip | d tion: | This co for a sp | mmand is u ecified axis | used to speces is analog | cify wheth or digital. | er the enco | der signal | | |
| Returns: | Returns: A read operation returns the following encoder mode values for the specified axis: $ \begin{array}{r} 0 & -\text{Digital} \\ 1 & -\text{Analog} \end{array} $ | | | | | | | | |
| Syntax: | | nEADx – Standard syntax nEAD? – Read encoder mode value 0EADx – All axes set encoder value Error [#]: xEAD – Missing encoder mode parameter [28] EAD? – Read operation with missing axis number [27] | | | | | | | |
| Paramete Descrip | er tion: | n[int] - x[int] - ? - | - Axis number - Encoder mode - Read encoder | e mode value | | | | | |
| Paramete Range: | er - | n - 0 to 99 X - 0 for digital, 1 for analog | | | | | | | |
| Related Comman | ds: | ENC | | | | | | | |
| Example | : | 9EADO | | | Axis 9, Set e | encoder to digit | al input | | |





Set Encoder Resolution

| During Motion | | Real-time | | Program | | Global | | |
|--|--------------|---|----------------------|---------|------|--------------|------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | |
| Command Description: | | This command is used to set the desired encoder resolution for the specified axis. When a digital encoder is connected, encoder resolution is determined by the encoder itself and the ENC setting will need to reflect this value. Analog encoder resolution is set by the controller. | | | | | | |
| Returns: | | A read operation returns the encoder resolution value for the specified axis. | | | | | | |
| Syntax: | | nENCx – Standard syntax nENC? – Read encoder resolution value 0ENCx – All axes execute encoder resolution value Error [#]: ENC? – Read operation with missing axis number [27] nENC – Missing encoder resolution parameter [28] | | | | | | |
| Parameter Description: | | n[int] — Axis number x[float] — Encoder resolution ? — Read encoder resolution value | | | | | | |
| Paramete Range: | r | n = 0 to 99 x = 0.001 to 999.999 µm/count (milli-degrees/count) | | | | | | |
| Related Comman | ds: | EAD | | | | | | |
| Example: 2ENC10 Axis 2, Set encoder resolution to 10 microns/count (10 milli- degrees/ | | | ount grees/count) | | | | | |



(END)

End Program Recording

| During Motion | | Real-time | | Program | | Global | | |
|---------------------------|------|--|---------|--|---------------|---------------|----------------------------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | \checkmark | | | | |
| Command Description: | | This command is used to exit out of program recording mode, which is initiated by the PGM command. The END command must be placed separately on the last line of the program sequence. The resulting program is saved upon exit for later use. | | | | | | |
| Returns: | | A read operation is not available with this command. | | | | | | |
| Syntax: | | nEND — Standard syntax | | | | | | |
| | | Error [#]: END — Missing axis number [30] | | | | | | |
| Parameter Description: | | n[int] – Axis number | | | | | | |
| Parameter Range: | | n - 1 to 99 | | | | | | |
| Related Comman | ds: | REC, EXC, PGM | | | | | | |
| Example | | 1 PGM | | Axis 1, H | Begin program | n recording | | |
| | : | <i>1VEL1</i> | ;1ACC.5 | Axis 1, Set velocity value to 1 mm/s; Axis 1, S acceleration value to 0.5 mm/s ² | | | Axis 1, Set nm/s ² | |
| | | [degrees/s 1END | 2] | | Axis 1, End | program recor | ding | |



EPL

| Encode | r Po | larity |
|---------|--------------|--------|
| Lincouc | I I U | iurity |

| During Motion | | Real-time | | Program | | Global | | |
|-------------------------|--|--|--------------|----------|---|------------------|---------------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | |
| Command Description: | | This command is used to switch the encoder signal polarity for the specified axis, which determines the physical direction of travel that the stage reads as positive (by default, moving away from where the wires enter the base of the stage is positive). NOTE: EPL, MPL and LDR must all be changed together to maintain proper functionality, changing one of these values without changing the rest will result in improper stage behavior. | | | | | | |
| Returns: | | A read operation returns the following encoder polarity values for the specified axis: 0 - Normal operation 1 - Reverse operation | | | | | | |
| Syntax: | | nEPLx — Standard syntax nEPL? — Read encoder polarity value 0EPLx — All axes execute encoder polarity value Error [#]: EPL? | | | | | | |
| Paramete Descript | ter $n[int]$ — Axis number x[float] — Encoder polarity iption: ? — Read encoder polarity value | | | | | | | |
| Paramete Range: | r | n = 0 to 99 x = 0 for normal operation, 1 for reverse operation | | | | | | |
| Related Comman | ds: | DBD | | | | | | |
| Example | : | 13EPL - 6EPL1 | 0 | Axis 13, | Set encoder p operation | oolarity to norn | nal y to reverse | |
| | | operation | | | , ,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,, | r · ···· | | |


ERA

| Erase Pro | Erase Program | | | | | | | | | |
|---|---------------|----------------------|---------------------------------------|--|---------------------------|---|------|--|--|--|
| During | Motion | Rea | l-time | Prog | ram | Glo | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | \checkmark | | | | | | | | |
| This command is used to erase a specified program from axis. Before recording a program, use the LST command see what program numbers are available for that axis. T are 16 program numbers available allowing up to 16 programs to be stored. An existing program cannot be overwritten and must be erased first. Therefore, use this command to erase the specified program and make spa- a new one. | | | | | | n from an nmand to kis. There 6 t be e this e space for | | | | |
| Returns: A read operation is not available with this command. | | | | | | ıd. | | | | |
| Syntax: | | nERAx Error [‡ | – Sta †]: ERAx – M nERA– Mis | andard syntax issing axis nur sing program | nber [30] number param | ueter [28] | | | | |
| Paramete Descrip | er tion: | n[int] - x[int] - | – Axis number – Program num | ber to be erase | ed | | | | | |
| Paramete Range: | er | n - 1 to x - 1 to | 99 16 | | | | | | | |
| Related Comman | ds: | LST | | | | | | | | |
| Example | : | 5era4 | | Axis 8, I | Erase program | ı 4 | | | | |



ERR

Read and Clear Errors

| During | Motion | Rea | l-time | Program | | Global | | |
|--|---|---|---------------------------------|--------------|----------------|---------|---------------------------|--|
| Set | Read | Set | Read | Set Read Set | | | Read | |
| | \checkmark | | \checkmark | | | | | |
| Comman Descrip | nmandThis command is used to read and clear any pending errorescription:messages. | | | | | | | |
| A read operation returns a list of error messages for the specified axis in the following format. "AAA" signifies the specific command name that the error corresponds to. Error Number – Description [AAA] | | | | | | | for the gnifies the s to. | |
| Syntax: | | nERR? – Standard syntax Error [#]: ERR? – Read operation with missing axis number [123] | | | | | | |
| Paramete Descrip | er tion: | n[int] ? | – Axis number – Read error m | iessages | | | | |
| Paramete Range: | r | n - 1 to | 99 | | | | | |
| Related Comman | ds: | None | | | | | | |
| Example | : | 3ERR? |) | Axis 3 | , Read error m | essages | | |



EST

Emergency Stop

| During | Motion | Rea | l-time | Prog | ram | Glo | obal | |
|---------------------|------------|--|---|---|--|--|-------------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| \checkmark | | \checkmark | | \checkmark | | \checkmark | | |
| Comman Descrip | d tion: | This co connect The cor | mmand is u ted axes sin ntroller exec | used to stop nultaneousl cutes the la | a specific y in case c rgest possi | axis or all of an emerg ible deceler | gency. cation. | |
| Returns: | | A read operation is not available with this command. | | | | | | |
| Syntax: | | nEST – Standard syntax 0EST – All axes execute emergency stop | | | | | | |
| Paramete Descrip | r tion: | n[int] - | - Axis number | | | | | |
| Paramete Range: | r | n = 0 to | 99 | | | | | |
| Related Comman | ds: | STP | | | | | | |
| F 1 | | 8EST | | Axis 8, I | Emergency sto | р | | |
| Example | : | - Oest | | All axes, | Emergency s | top | | |



(EXC)

Execute Program

| During | Motion | Real | -time | Program | | Global | |
|---|------------|--|--|--|---|---|--------------------------------------|
| Set | Read | Set | Read | Set | Read | Set | Read |
| | | \checkmark | | | | \checkmark | |
| Comman Descrip | d tion: | This co one or 1 connect under th | mmand is u nultiple axe red axes sho ne specified | used to exect es. If execu ould have in program r | cute a spec ting a prog ndividual j number pri | ified progr gram globa programs st or to execu | am for lly, all cored tion. |
| Returns: | | A read | operation is | not availa | ble with th | nis comman | nd. |
| nEXCx – Standard syntax 0EXCx – All axes execute program Syntax: Error [#]: nEXC – Missing program number parameter [12 | | | | | | neter [123] | |
| Paramete Descript | r tion: | n[int] x[float] | — Axis numbe — Program nu | er mber to be exe | ecuted | | |
| Paramete Range: | r | $n = 0$ to $\frac{9}{x}$ $x = 1$ to $\frac{9}{x}$ | 99 54 | | | | |
| Related Comman | ds: | PGM | | | | | |
| Example | : | 4EXC5 - | | Axis 4, E | Execute progra | am 5 | |
| | | 0EXC2 | | | All axes, Ex | ecute program | 2 |



(FBK)

Set Open or Closed Loop Mode

| During | Motion | Rea | l-time | Prog | ram | Glo | obal |
|--|--|-----------------------------------|--|--------------------------------------|---------------------------|-----------------|------------|
| Set | Read | Set | Read | Set | Read | Set | Read |
| | \checkmark | \checkmark | \checkmark | | | | |
| Comman Descript | d tion: | This co control | mmand is u ler. See sect | used to sele tion 4.2 for | ct the feed more deta | back mode | of the |
| A read operation returns the following loop mothe specified axis: 1. – Open Loop [default] Returns: 2. – Clean Open Loop 3. – Clean Open Loop Movement, Closed deceleration 4. – Closed Loop | | | | | | oop mode v | values for |
| Syntax: | NFBKx- Standard syntax nFBK? - Read encoder mode value Syntax: Error [#]: FBKx - Missing axis number [30] FBK? - Read operation with missing axis number [27] PEPK Minimum Language (201) | | | | | | 7] |
| Paramete Descript | r tion: | n[int] x[float] ? | Axis number Open/close Read encode | er ed loop mode ler mode value | | | |
| Paramete Range: | r | n - 1 to x - 0 fo loop with | 99 r open loop mo closed loop dea | de, 1 for clean celeration, 3 cl | sounding ope osed loop | en loop mode, 2 | 2 for open |
| Related Comman | ds: | ENC, E | AD, EPL, I | DBD | | | |
| Example: | : | 2FBK3 | | Axis 2, S | Set closed loop | p mode | |



(HCG)

Home Configuration

| During | Motion | Real | -time | Prog | ram | Glo | obal | | |
|--|--------------|---|---|--------------------|------|-------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | \checkmark | | | | | |
| Command Description:This command is used to select the direction of motion when the Home [HOM] command is initialized. | | | | | | otion | | | |
| Returns: | | A read | A read operation returns the current direction setting: 0 – Home starts in the direction of the negative limit 1 – Home starts in the direction of the positive limit | | | | | | |
| nHCGx – Standard syntax 0HCGx – All axes set direction nHCG? – Read direction setting Syntax: Error [#]: HCG? – Read operation with missing axis number [27] nHCG – Missing direction setting [28] | | | | | | 7] | | | |
| Paramete Descript | r tion: | n[int] x [int] | Axis numb Set direction | er n of motion. | | | | | |
| Paramete Range: | r | n - 0 to 99 X - 0 for setting motion in the direction of the negative limit 1 for setting motion in the direction of the positive limit | | | | | | | |
| Related Comman | ds: | HOM | | | | | | | |
| Example: | | 3HCG0 Axis 3, Set initial direction of Home command towards the negative limit - - 0HCG1 All Axes, Set initial direction of Home command towards the positive limit | | | | | | | |



HOM)

| Home | | | | | | | | |
|---------------------|--------------|--|---|--|---|--|--|--|
| During | Motion | Real | l-time | Program | | Glo | obal | |
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | |
| Comman Descrip | d tion: | This co specifie signal a the HC reaches then acc This co during | mmand is u ed axis. An t the time of G command the limit of quire the ho mmand blo motion. | error will of execution d. This com onfigured vo me positio cks all com | the home occur if the h. Home is mand will with the Ho n by looki municatio | position for ere is no en configured l jog the sta CG comma ng for the i on over the | or a acoder 1 using age until it nd. It will ndex. serial port | |
| Returns: | | A read parameter returns the following calibration values for the specified axis: 0 - Not calibrated to home position 1 - Calibrated to home position | | | | | | |
| Syntax: | | nHOM nHOM' 0HOM Error [# | — Standard s ? — Returns 1 — All axes e #]: HOM? — Ra | syntax if homed since xecute home p ead operation v | e last startup o osition with missing a | otherwise return txis number [2 | ns 0 7] | |
| Paramete Descrip | r tion: | n[int] | — Axis number | r | | | | |
| Paramete Range: | r | n = 0 to 99 | | | | | | |
| Related Comman | ds: | HCG | | | | | | |
| Example | : | 1HOM | | Axis 1, N | Move to home | position | | |



(IOD)

Set IO Definition

| During | Motion | Real-time | | Program | | Global | | | | |
|----------------------|---|--|--|------------------------------|-----------------|------------|------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | \checkmark | | | | | | | | |
| Comman Descrip | CommandThis command is used to select Input or Output for one of the IO pins on the 8-Pin Din connector. | | | | | | | | | |
| Returns: | | A read | operation is | s not availa | ble with th | nis commar | ıd. | | | |
| | | nIODx1,x2 — Standard syntax nIOD? — Read encoder mode value | | | | | | | | |
| Syntax: | | Error [#]: IODx1,x2 – Missing axis number [30] IOD? – Read operation with missing axis number [27] nIOD – Missing closed/open loop parameter [28] | | | | | | | | |
| Paramete Descript | r tion: | n[int] x1[int] x2[int] ? | Axis nur IO Pin Input/ O Read end | nber Dutput coder mode | e value | | | | | |
| Paramete Range: | r | n - 1 to 99 $x1 - 1 - IO1 (output only)$ $2 - IO2$ $3 - IO3$ $4 - IO4$ $x2 - 0 - Output$ $1 - Input$ | | | | | | | | |
| Related Comman | ds: | IOF | | | | | | | | |
| Example | : | 210D2 | ,1 | Axis 2, S | Set IO2 to an I | nput | | | | |



| Set IO Fu | unction | | | | | | | |
|---|------------|---|---|---|--|-----------------|-----------------------|--|
| During | Motion | Real-time Program | | Glo | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | | | | | |
| Comman Descrip | d tion: | This command is used to select the function of an IO pin. | | | | | | |
| Returns: | | A read | operation is | s not availa | ble with th | nis commar | ıd. | |
| nIOFx1,x2 – Standard syntax nIOF? – Read encoder mode value | | | | | | | | |
| Syntax: Error [#]: IOFx1,x2 - Missing axis number [30] IOF? - Read operation with missing axis number [nIOF - Missing closed/open loop parameter [28] | | | | | | | umber [27] er [28] | |
| n [int] – Axis number Parameter x1[int] – IO Pin Description: x2 [int] – IO Function ? – Read encoder mode value | | | | | | | | |
| Paramete Range: | 21 | n - 1 $x1 - 2$ 3 4 $x2 - 1$ 2 3 | to 99 1 – IO1 – IO2 – IO3 – IO4 0 – No fund – Trace dat – Output pr – Output le | ction a acquisiti ulse trigger evel when i | on on trigg r when in p n position | ger position | | |
| Related Comman | ıds: | IOD | | | | | | |
| Example | : | 210F2 trigger | ,1 | Axis 2 | 2, Set IO2 | to data logg | ging | |



(JAC)

Jog Acceleration and Deceleration

| During | Motion | Rea | l-time | Prog | ram | Glo | obal | | |
|---------------------|--------------|--|--|---|--|------------------------------------|-----------------------------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | |
| Comman Descrip | d tion: | This co accelera controll AMX. | mmand is u ation and de ler will not | used to set t eceleration allow for J | the desired for a spec AC values | value for t ified axis. | he jog The eater than | | |
| Returns: | | A read deceler | operation re ation value | eturns the j in mm/s ² fe | og acceler or the spec | ation and ified axis. | | | |
| Syntax: | | nJACx – Standard syntax 0JACx – All axes execute acceleration value nJAC? – Read acceleration value Error [#]: JAC? – Read operation with missing axis number [27] nJAC – Missing acceleration parameter [28] | | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] ? | — Axis num — Accelerati — Read acce | ber on leration value | | | | | |
| Paramete Range: | r | n = 0 to x = .001 | 99 to 500.000 mr | n/s ² [degrees/s ² | ²] | | | | |
| Related Comman | ds: | ACC, I | ACC, DEC, AMX | | | | | | |
| Example | : | 4 JAC 0 decelerati | .1 on to | | Axis 4, Set j 0 | og acceleratior 0.1 mm/s² [degr | n & ees/s ²] | | |



JOG

| Jog Mode | e | | | | | | | | | |
|--|------------|--|--|-------------|---------|-----|------|--|--|--|
| During | Motion | Rea | -time | Prog | ram | Glo | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| \checkmark | | \checkmark | | | | | | | | |
| Comman Descrip | d tion: | This co continu velocity be chan during | This command is used to jog a specific axis, or move continuously in a direction with no target position. The jog velocity is a percentage of the maximum velocity and may be changed on-the-fly by sending another JOG command during motion. | | | | | | | |
| Returns: A read operation is not available with this command. | | | | | | | nd. | | | |
| Syntax: | | nJOGx – Standard syntax Error [#]: JOGx – Missing axis number [30] nJOG – Missing velocity parameter [28] | | | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] | Axis numb Velocity | er | | | | | | |
| Paramete Range: | r | n - 1 to $x = 0$ to $z = 1$ | 99 ±100.000 % (of | maximum vel | locity) | | | | | |
| Related Comman | ds: | JAC | | | | | | | | |
| Commands.4 JOG10 Axis 4, Jog at 10% maximum velocityExample:2JOG-50 Axis 2, Jog in the negative direction at 50% maximum velocity | | | | | | | ty | | | |





Limit Configuration

| During | Motion | Real-time | | Prog | ram | Gle | obal | | |
|---|--------------|---|---|----------------|-----------------|--------------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | |
| CommandThis command selects how the stage will detect it's end limits using a limit switch or using the encoder to detect a hard stop. | | | | | | | | | |
| Returns: | | A read of | peration ret | urns the sele | cted limit t | ype. | | | |
| Syntax: | | nLCGx – Standard syntax Error(s): LCGx – Missing axis number [30] nLCG – Missing program number parameter [28] | | | | | | | |
| Parameter Descripti | ion: | n[int] – x[int] – | Axis number 0 – ignore [defa – active | ult] | | | | | |
| Parameter Range: | | n - 1 to 99 x - 0 - ignore [default] 1 - Home and MLN/MLP use Soft Limits 2 - Limits Switches Enabled 3 - Home and MLN MLP use Soft Limits and Limit Switches enabled | | | | | | | |
| Related C | ommands: | LPL | | | | | | | |
| Example: | | 1LCG1 | | Axis 1, set li | mit switches ac | ctive | | | |





Positive/ Negative Limit Location

| During Motion | | Real-time | | Program | | Global | |
|--|---|-----------------------------|--|--------------------|------|--------|------------------------------|
| Set | Read | Set | Read | Set | Read | Set | Read |
| CommandDetermines orientation of Positive limit, and negative limit.CommandNOTE: EPL, MPL and LDR must all be changed together to maintain proper functionality, changing one of these values with changing the rest will result in improper stage behavior. | | | | | | | nit. er to ies without |
| Returns: A read operation returns the following limit direction values for specified axis: 0 - Normal orientation 1 - Reverse orientation | | | | | | | |
| nLDRx – Standard syntax nLDR? – Read velocity value 0LDRx – Missing axis number, all axes set limit direction Syntax: Error [#]: LDR? – Read operation with missing axis number [27] nLDR – Missing limit parameter [28] | | | | | | | |
| Parameter Descripti | on: | n[int] – x[int] – ? – | Axis number limit direction v Read limit direc | alue tion value | | | |
| Parameter Range: | Parameter $n - 0 \text{ to } 99$ Range: $X - 0 \text{ or } 1$ | | | | | | |
| Related Co | ommands: | | | | | | |
| ILDR1 Axis 1, set to reverse orientation Example: - 5LDR? Axis 5, Read limit switch orientation | | | | | | | |



LIM

Limit Status

| During | Motion | Real | -time | Prog | ram | Global | | | |
|--|--------------|---|--------------------------------|----------------|-------------------|--------|--------------|--|--|
| Set | Read | Set | Read | Set Read | | Set | Read | | |
| | \checkmark | | \checkmark | | \checkmark | | \checkmark | | |
| Command Description:Returns the status of both limit switches in the form LSP, LSN. This is useful for limit switch configuration. | | | | | | | | | |
| Returns: A read operation returns current limit status for the specified axis. | | | | | | | | | |
| Syntax: | | nLIM? — Standard syntax Error [#]: LIM? — Read operation with missing axis number [123] | | | | | | | |
| Parameter Descripti | on: | n[int] - As ? - Re | kis number ad limit switche | 25 | | | | | |
| Parameter Range: | | n − 1 to 99 | | | | | | | |
| Related Co | ommands: | None | | | | | | | |
| Example: | | 6LIM? | | Axis 6, read c | urrent limit stat | us | | | |



LST

| Program List | | | | | | | | | | |
|--|-------------|------------------|--|---------|-----------------|--|--------|--|--|--|
| During | Motion | Rea | l-time | Prog | gram | G | lobal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | | \checkmark | | | | | | | |
| Command Description: This command is used to display the individual command of the user to create the specified program. NO Commands are returned sequentially and individually, which means in the Micronix GUI they will be listed from bottom (first returned) to top (last returned). | | | | | | ommands n. NOTE: ally, ted from | | | | |
| Returns: A read operation returns the program table for the specifaxis. | | | | | | specified | | | | |
| Syntax: Error [#]: 1LST? – Read Not Available For This Command [38] | | | | | | | | | | |
| Paramete Descrip | er tion: | n[int] x[int] | Axis number Program# to | be read | | | | | | |
| Parameter $n - 1$ to 99Range: $x - 1$ to 16 | | | | | | | | | | |
| Related Comman | ds: | None | | | | | | | | |
| Example | : | 6LST1 | - | Axis 6 | , return progra | m 1 list of co | mmands | | | |



LPL

Limit Switch Polarity

| During | Motion | Rea | l-time | Pro | gram | G | lobal | | |
|-------------------|--------------|--|----------------------------|--------------------|---------------|------------|--------|--|--|
| Set | Read | Set | Read | Set Read | | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | | | | |
| Comman Descrip | d tion: | This co active | ommand set high[1] or l | s whether ow[0] | the limit sv | witch inpu | ts are | | |
| Returns: | | A read operation returns the limit polarity value. | | | | | | | |
| | | nLPLx — Standard syntax | | | | | | | |
| Syntax: | | Error(s |): | | | | | | |
| • | | | LPLx – N | Aissing axis n | umber [30] | | | | |
| | | | nLPL – N | lissing progra | m number para | meter [28] | | | |
| | | n[int] | - Axis numb | oer | | | | | |
| Paramete | r | x | -0 – Acti | veLow | | | | | |
| Descrip | tion: | A | -1 - Act | ive High | | | | | |
| Doromoto | r | n - 1 to | 99 | | | | | | |
| Dongo | 1 | x -0- | - active low [de | efault] | | | | | |
| Kange. | | 1– a | ctive high | - | | | | | |
| Related Comman | ds: | LCG | | | | | | | |
| Example | : | 6LPL1 Axis 5, limit switches set to active high | | | | | | | |



(MLN)

Move to Negative Limit

| During | Motion | Rea | -time | Program | | Global | | |
|--|------------|---|-------------|--------------|--|--|-------------|--|
| Set | Read | Set | Read | Set Read | | Set | Read | |
| | | \checkmark | | \checkmark | | \checkmark | | |
| This command initiates a move to the negative limit position. Upon reaching the negative hard limit the controller will then move the stage back from the hard lin and stop. If hard stop detection using the encoder (LCG0 active, an error will occur if there is no encoder signal at time of execution. | | | | | | it e hard limit LCG0) is gnal at the | | |
| Returns: | | A read operation is not available with this command. | | | | | | |
| Syntax: | | nMLN – Standard syntax OMLN – All axes execute move to negative limit position Error [#]: MLN – Missing axis number [30] | | | | | | |
| Paramete Descrip | r tion: | n[int] | — Axis numb | er | | | | |
| Paramete Range: | r | n = 0 to | 99 | | | | | |
| Related Comman | ds: | MLP, LCG | | | | | | |
| 8MLN Axis 8, Move to negative limit positive Example: - 0MLN All Axes, Move to negative limit positive | | | | | | ive limit positi gative limit pos | on ition | |



(MLP)

Move to Positive Limit

| During | Motion | Rea | l-time | Prog | ram | Global | | |
|--|--|--------------|-------------|--------------|------|--------------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | \checkmark | | \checkmark | | |
| Command Description: Inis command initiates a move to the positive limit positive tupon reaching the positive hard limit the controller will then move the stage back from the hard limit and stop. I hard stop detection using the encoder (LCG0) is active, a error will occur if there is no encoder signal at the time o execution. | | | | | | | t position. r will top. If ctive, an time of | |
| Returns: | S: A read operation is not available with this command. | | | | | | | |
| Syntax: | nMLP – Standard syntax OMLP – All axes execute move to positive limit position ax: Error [#]: MLP – Missing axis number [30] | | | | | | | |
| Paramete Descrip | er tion: | n[int] | — Axis numb | er | | | | |
| Paramete Range: | r | n = 0 to | 99 | | | | | |
| Related Comman | ds: | MLN, LCG | | | | | | |
| 1MLP Axis 1, Move to positive limit position Example: - 0MLP All Axes, Move to positive limit position | | | | | | on ition | | |
| | | | | | _ | | | |



(MOT)

Toggle Motor Off/On

| During | Motion | Real-time | | Program | | Global | | |
|--|---|--|--|--|----------------|--------------|-------------------------------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | |
| Command Description: This command is used to turn the motor current flow " or "On" for a specified axis. Turning the motor current will cause the piezo to relax and the stage will shift sli | | | | | | | ow "Off" rent off t slightly. | |
| Returns: A read operation returns the following motor current off/ values for the specified axis: 0 - Motor current is off 1 - Motor current is on | | | | | | | | |
| Syntax: | nMOTx – Standard syntax nMOT? – Read motor current off/on value OMOTx – All axes set motor value x: Error [#]: MOT? – Read operation with missing axis number [27] xMOT – Missing motor off/on parameter [28] | | | | | | | |
| Paramete Descript | r tion: | n[int] x[float] ? | Axis num Motor curr Read motor | ber rent off/on r current off/or | n value | | | |
| Paramete Range: | r | n - 0 to 99 x - 0 for motor current off 1 for motor current on | | | | | | |
| Related Comman | ds: | None | | | | | | |
| Example: | | 1MOT0 | | Axis1, S | et motor curre | ent to off | | |



| MPI | Toggle Motor Polarity | | | | | | | | | |
|-----|---|-------------|--|---|--|--|----------------------------|----------|--|--|
| | During | Motion | Rea | l-time | Prog | ram | Glo | obal | | |
| | Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | v | This or | v mmond sot | the motor | nolority fo | r the specif | ind avia | | |
| | Comman Descrip | d tion: | If the theoretical positive direction is away from the motor, changing this setting will make the theoretical positive direction towards the motor. NOTE: EPL, MPL and LDR must all be changed together to maintain proper functionality, changing one of these values without changing the rest will result in improper stage behavior. | | | | | | | |
| | Returns: | | A read for the | operation respecified as | eturns the c kis. | current mo | tor polarity | setting | | |
| | Syntax: | | nMPL3 nMPL3 0MPL3 Error [a | K — Standard sy ? — Read motor K — All axes se #]: MPL? — F nMPL — N | /ntax r current off/or t motor value Read operation dissing motor of | n value with missing off/on parame | axis number [2 ter [28] | 27] | | |
| | Paramete Descrip | er tion: | 1 value | | | | | | | |
| | Parameter Range: $n - 0 \text{ to } 99$ $X - 0 \text{ Normal}$ 1 Reverse | | | | | | | | | |
| | Related Comman | ds: | MVR | | | | | | | |
| | Example | : | 1MPLC |) | Axis1, T | o normal Pola | arity | | | |



(MSA)

| Synchronous Move - Absolute | | | | | | | | | | |
|--|------------|--|---|---|--|--|---|--|--|--|
| During | Motion | Rea | l-time | Prog | Program | | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | | \checkmark | | | | \checkmark | | | | |
| Comman Descrip | d tion: | This co absolut coordin more ay to exect comma | mmand is u e position. T aating motic kes and requ ute the sync nded positio | used to set u This comm on to an abs uires a RUI chronous m on is outsic | up a synch and is mos solute posi N comman ove. An e le of the so | ronous mov st useful wh tion betwee d on a sepa error will oc oft limits. | ve to an nen en 2 or urate line ccur if the | | | |
| Returns: | | A read | operation is | s not availa | ble with th | nis comman | ıd. | | | |
| nMSAx – Standard syntax 0MSAx – All axes execute synchronous move Syntax: Error [#]: nMSA – Missing absolute position parameter [28] | | | | | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] | — Axis num — Absolute j | ber position | | | | | | |
| Paramete Range: | r | n = 0 to x = -999 | 99 9.999999 to 999 | 9.999999 mm (| (degrees) | | | | | |
| Related Comman | ds: | RUN, N | MSR | | | | | | | |
| Example | : | 1MSA10; 2MSA10 Axis 1, Move to absolute position: 10 mm[degrees]; Axis 2, Move to absolute position: 10 mm [degrees] ORUN All axes, Execute synchronous move - 0MSA5 mm [degrees] ORUN All axes, Move to absolute position: 5 mm [degrees] ORUN All axes, Execute synchronous move | | | | | | | | |



(MSR)

| During | Motion | Rea | l-time | Prog | ram | Glo | obal | |
|----------------------|--|--|---|--|-------------------------------|--------------------|------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | | | \checkmark | | |
| Comman Descrip | d tion: | This command is used to set up a synchronous move to a position relative to the current position. This command is most useful when coordinating relative positions between 2 or more axes and requires a RUN command on a separate line to execute the synchronous move. An error will occur if the commanded increment will cause the stage to travel outside of the set soft limits. | | | | | | |
| Returns: | urns: A read operation is not available with this command. | | | | | | | |
| Syntax: | | nMSRx 0MSAx Error [# | 4 — Sta 4 — Al ¢]: nMSA — M | andard syntax l axes execute issing relative | synchronous position parar | move neter [28] | | |
| Paramete Descript | r tion: | n[int] x[float] | Axis number Relative potential | er sition | | | | |
| Paramete Range: | r | n = 0 to $x = \pm 0.$ | 99 000001 to 999. | 999999 mm (d | egrees) | | | |
| Related Comman | ds: | RUN, N | MSA | | | | | |
| Example: | | 4MSR.1;5MSR.5 Axis 4, Move 0.1 mm [degrees]; Axis 5, Move 0.5 mm [degrees] 0RUN Execute synchronous move - 0MSR0.01 0RUN All axes, Move 0.01 mm [degrees] | | | | | | |







Move Absolute

| During | Motion | Real-time | | Program | | Global | | | |
|---------------------|--|---|----------------------------|-----------------|-------------|--------------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | \checkmark | | \checkmark | | \checkmark | | | |
| Comman Descrip | mmand escription: This command is used to initiate an instantaneous move to an absolute position for a specified axis. An error will occ if the commanded position is outside of the soft limits. | | | | | | | | |
| Returns: | | A read | operation i | s not availa | ble with th | nis commar | nd. | | |
| Syntax: | | nMVAx – Standard syntax OMVAx – All axes execute instantaneous move Error(s): nMVA – Missing absolute position parameter [28] | | | | | | | |
| Paramete Descrip | er tion: | n[int] x[float] | — Axis num — Absolute j | ber position | | | | | |
| Paramete Range: | r | n — 0 to x — -999 | 99 .999999 to +99 | 99.9999999 mm | (degrees) | | | | |
| Related MVR, WFS | | | | | | | | | |
| Example | : | 4MVA14.5 Axis 4, Move to absolute position: 14.5 mm [degrees] - 0MVA5.5 All axes, Move to absolute position: 5.5 mm [degrees] | | | | | | | |



(MVR)

| Move Re | lative | | | | | | | | |
|---|-------------|--|---|------------------------------|-------------|--------------|------|--|--|
| During | Motion | Real | -time | Prog | ram | Glo | obal | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | \checkmark | | \checkmark | | \checkmark | | | |
| Comman Descrip | d tion: | This co relative the con outside | This command is used to initiate an instantaneous move to a relative position for a specified axis. An error will occur if the commanded increment will cause the stage to travel outside of the set soft limits. | | | | | | |
| Returns: | | A read | operation is | s not availa | ble with th | nis commai | nd. | | |
| nMVRx – Standard syntax 0MVRx – All axes execute command. Syntax: Error(s): nMVR – Missing relative position parameter [28] | | | | | | | | | |
| Paramete Descrip | er tion: | n[int] x[float] | — Axis num — Relative p | ber osition | | | | | |
| Paramete Range: | er | $\begin{array}{ll} n & -0 \\ x & -\pm 0 \end{array}$ | to 99).000001 to ± 9 | 99.999999 mn | n [degrees] | | | | |
| Related Comman | ds: | MVR, WFS | | | | | | | |
| Example | : | 6MVR1 - 0MVR. | 0 89 | Axis 6, Move 10 mm [degrees] | | | | | |



PGL

| Loop Program | | | | | | | | | | |
|---------------------|--|--|---|---|--|--|--|--|--|--|
| During | Motion | Rea | l-time | Program | | Glo | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| | \checkmark | \checkmark | \checkmark | | | \checkmark | | | | |
| Comman Descrip | d tion: | This cc program program can be continu PGL to sending This ve 1.4.53 1/0. | ommand is un n will exect n that is ex- combined we ously on st 1. A looping the STP of ersion of the and up. Price | used to cha ute. If the p ecuted will with the PG artup. To d ing program r EST com e command or versions | nge the nu program lo run in a co S commar lisable pro n can be st mands. l available have an or | mber of tin op setting i ontinuous l nd to run a gram loopin opped at an in firmwar n/off PGL s | nes a s 0, any oop. It program ng, set ny time by e version setting | | | |
| Returns: | | A read specific | operation r ed axis. | eturns the | program lo | oop setting | for the | | | |
| Syntax: | | nPGLx Error(s | - Standard): PGLx - M nPGL - M | syntax Aissing axis nu Aissing program | umber [30] m number par | ameter [28] | | | | |
| Paramete Descrip | er tion: | n[int] x[int] | – Axis number – loop flag par | ameter | | | | | | |
| Paramete Range: | Parameter Range: n - 1 to 99 x - 0 - Loop indefinitely 1 - Don't Loop 2 to 999999 - number of times an executed command will repeated | | | | | | | | | |
| Related Comman | ds: | PGS, S | TP | | | | | | | |
| Example | : | 1PGL0 Axis 1, Run program 1 continuously1PGL5 Axis 1, Run program 5 times | | | | | | | | |





Begin Program Recording

| During | Motion | Real-time | | Program | | Global | | |
|---|--------------|--|---|---|--|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | \checkmark | \checkmark | | | | | |
| Comman Descrip | d tion: | This co a speci- unique Us the availab previou limit of | ommand is trified axis. T program nu PGM? com ility and us usly recorde f 4Kb. | used to ento he program umber or el imand to cl e the ERA ed program | er program n being rec lse the prog neck progr command s. Each pr | orded must orded must gram will b am number to erase an ogram has | mode for t use a te ignored. ty a size | |
| Returns: A read operation in not available for this command | | | | | | | đ | |
| Syntax: | | nPGMx – Standard syntax nPGM? – Read a binary representation of written program numbers If programs 1 and 2 are written it will return 3 If programs 1 and 4 are written it will return 9 If only program 1 is written it will return 1 If only program 3 is written it will return 4 Error(s): PGMx – Missing axis number [30] | | | | | nbers | |
| Paramete Descrip | er tion: | n[int] x[int] | – Axis number – Program nun | nber to be reco | orded | | | |
| Paramete Range: | er | n - 1 to 99 x - 1 to 16 | | | | | | |
| Related Comman | ıds: | END, EXC, LST, ERA | | | | | | |
| Example | : | 1PGM3 | } | Axis 1, as program | Begin recordi m 3 | ng program. Sa | we program | |



(PGS)

Run Program At Start-Up

| During | Motion | Rea | l-time | Pro | gram | Global | |
|--|------------|---|---|--|--|--------------------------------|--------------------------|
| Set | Read | Set | Read | Set | Read | Set | Read |
| | | \checkmark | \checkmark | | | \checkmark | |
| Comman Descrip | d tion: | This co on star | ommand is t t-up. Only o | used to set | a program m per axis | to run imi can run or | mediately 1 start up. |
| Returns: | | A read format | operation r below: 0 - No p 1-16 - Pr | eturns a va program set to rogram set to | alue for the run run on start-up | specified | axis in the |
| nPGSx — Standard syntax OPGSx — Missing axis number, all axes set nPGS? — Read program(s) set to run on sta Syntax: Error [#]: PGS? — Read operation with missi | | | | | | ram to run on s number [27] | start-up |
| | | n | PGS – Miss [28] | sing program | set to run on st | art-up parame | eter |
| Paramete Descrip | r tion: | n[int] x[float] ? | Axis numb Program s Return number | ber et to run on st nber of progra | art-up am set to run o | n startup. | |
| Paramete Range: | r | n = 0 to x = 0 - 1 to | 99 No program 16- Specific p | program set to | run on start-uj | p | |
| Related Comman | ds: | LST, P | GM | | | | |
| | | 6PGS5 |) | Axis 6 | , set program 5 | 5 to run on sta | rt-up |
| Example | | 0PGS1 _ | . 6 | All ax | es, set program | 16 to run on | start-up |
| Example | • | 3PGS? Axis 3, Read program to run on start-up | | | | | |
| | | 3PGS(|) | Axis 3 | , Set no progra | um to run on s | tart-up |



PID

Set Feedback Constants

| During | Motion | Real-time | | Program | | Global | | | |
|--|---|--|---|---|---|--------------------------------|----------------------|--|--|
| Set | Read | Set | Read | Set Read | | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | | | | | | |
| Comman Descript | nmandThis command is used to set the encoder feedback gain constants for a specified controller. | | | | | | gain | | |
| Returns: | | A read values | operation re for the spec | eturns the e fiied axis. | encoder fe | edback con | stant | | |
| nPIDx1,x2,x3 — Standard syntax nPID? — Read encoder feedback constant | | | | | | stant values | | | |
| Syntax: | | Error(s): PIDx1,x2,x3 – Missing axis number [30] PID? – Read operation with missing axis number [2 nPID – Missing encoder feedback constant parameter [28] | | | | | | | |
| Paramete Descript | r tion: | n[int] x1[floa x2[floa x3 [floa ? | $ \begin{array}{c} - A_{i} \\ t] & - K_{i} \\ t] & - K_{i} \\ at] & - K_{i} \\ - Read end \end{array} $ | xis number (proportional (integral cons (derivative co coder feedback | constant) stant, stepper o onstant, steppe constants and | only) er only) 1 values | | | |
| Paramete Range: | r | $\begin{array}{rrrr} n & -1 \ t \\ x1 & -0.0 \\ x2 & -0.0 \\ x3 & -0.0 \end{array}$ | o 99)00 to 2.000)00 to 2.000)00 to 2.000 | | | | | | |
| Related Comman | ds: | FBK, F | ENC, POS | | | | | | |
| | | 5PID. to 0.02, | 02,.04, | .05 0.04 ar | Axis 5, Set ad 0.05, respec | encoder feedba ctively | ick constants | | |
| Example: | | 2PID. K _p to | 03,, | 0.03, o | Axis 2, Set | encoder feedba remain uncha | ick constant nged | | |
| | | 4PID, K _d to | -4PID,,.07Kd to0.07, other constants remain unchanged | | | | | | |



POS

Position

| During Motion | | Rea | l-time | Pro | gram | G | lobal | | |
|---|--------------|---|---|----------|------|-----------|-------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | | \checkmark | | | | | | |
| Comman Descrip | d tion: | This co the spe | This command is used to read the position information from the specified axis controller | | | | | | |
| Returns: A read operation returns the position values in mm for the specified axis in the following format: [Theoretical position in mm, Encoder position in mm] [Theoretical position in degrees, Encoder position in degrees] | | | | | | n for the | | | |
| Syntax: | | nPOS? – Standard syntax Error(s): POS? – Read operation with missing axis number [27] | | | | | | | |
| Paramete Descrip | er tion: | n[int] ? | – Axis number – Read positio | n values | | | | | |
| Paramete Range: | er | n - 1 to | 99 | | | | | | |
| Related Comman | ds: | MVR | | | | | | | |
| Example | : | 4POS? Axis 4, Read position values | | | | | | | |



REZ

| Set Reso | Set Resolution | | | | | | | | | | | |
|---------------------|----------------|---------------------------|---|---|---|---------------------------------|-----------------------------|--|--|--|--|--|
| During | Motion | Rea | l-time | Program | | Global | | | | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | | | |
| | \checkmark | \checkmark | \checkmark | | | | | | | | | |
| Comman Descrip | d tion: | This co conver | ommand is ter) steps pe | used to set er micron i | the DAC (resolution f | digital to a for the spe | analog cified axis. | | | | | |
| Returns: | | A read micron | A read operation returns the resolution value in steps per micron for the specified axis. | | | | | | | | | |
| Syntax: | | nREZx nREZ? Error(s | - Standard s - Read steps): REZ? - R REZx - M nREZ - M | yntax per micron re ead operation issing axis nu issing steps p | esolution value with missing a mber [30] er micron resol | ixis number [2 | 27] ter [28] | | | | | |
| Paramete Descrip | er tion: | n[int] x[float] ? | Axis numb Steps per 1 Read steps | per nicron resolut per micron re | ion (steps/mili esolution value | -degrees) (de (steps/milli-o | fault is 8,000) legrees) | | | | | |
| Paramete Range: | er | n - 1 to x - 0 to | 99 9999999 DAC | steps per micr | on (steps/milli | -degrees) | | | | | | |
| Related Comman | ds: | None | | | | | | | | | | |
| Example | : | 9REZ2 - | 9REZ25 Axis 9, Set resolution to 25 steps/micron [steps/milli-degrees] | | | | | | | | | |
| | | 3REZ? |) | Axis 3 resolu | , Read steps/n ition value | nicron [steps/ | degrees] | | | | | |



RST

Perform Soft Reset

| During | Motion | Real-time | | Pro | gram | Global | | | |
|---|-------------|--|---|-----|------|--------------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | \checkmark | | | | \checkmark | | | |
| Comman Descrip | d tion: | This co specific stack, i ANR is another become | This command is used to perform a soft reset of the specified axis. Unsaved settings will be lost. In a multi axis stack, if only one axis is restarted using this command and ANR is set to 0, that axis will address as "1", even if another axis is already addressed as "1" causing an axis to become unresponsive. To correct this, restart all axes. | | | | | | |
| Returns: A read operation cannot be used with this command | | | | | | nd. | | | |
| Syntax: nRST - Standard syntax ORST - All axes execute soft reset | | | | | | | | | |
| Paramete Descrip | er tion: | n[int] | — Axis number | | | | | | |
| Paramete Range: | er | n - 1 to 99 | | | | | | | |
| Related Comman | ds: | None | | | | | | | |
| Example | : | 8RST Axis 8, execute soft reset | | | | | | | |



RUN

Start Synchronous Move

| During | Motion | Real-time | | Pro | gram | Global | | | |
|--|------------|-----------------------|--|--------|------------------------------|------------------------------|-------------------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | \checkmark | | | | \checkmark | | | |
| Comman Descrip | d tion: | This co previou | This command is used to start a global synchronous move previously set up by using the MSA or MSR commands. | | | | | | |
| Returns: A read operation cannot be used with this con | | | | | nis comma | nd. | | | |
| Syntax: | | RUN — Standard syntax | | | | | | | |
| Paramete Descrip | r tion: | - | | | | | | | |
| Paramete Range: | r | - | | | | | | | |
| Related Comman | ds: | MSA, MSR | | | | | | | |
| Example: | | 3MSR5 | 5;4MSR5 | Axis | Axis 3, set 4, setup 5 mm | up 5 mm[degi [degrees] mo | rees] move; ve | | |
| pro | - | ORUN | | All ax | es, Execute syr | nchronous mo | ves | | |



(SAV)

Save Axis Settings

| During | Motion | Rea | l-time | Pro | gram | G | lobal | |
|---|-------------|--|--------------------------------|-----------------------------|---------------|----------------------|---------------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | | | \checkmark | | |
| Comman Descrip | d tion: | This co axis. T | ommand is this allows a | used to sav an axis to b | ve all settin | gs for the ed on pow | specified er up. | |
| Returns: | | A read operation cannot be used with this command. | | | | | | |
| Syntax: nSAV – Standard syntax 0SAV – All axes save settings | | | | | | | | |
| Paramete Descrip | er tion: | n[int] | — Axis number | ſ | | | | |
| Paramete Range: | r | n = 0 to |) 99 | | | | | |
| Related Comman | ds: | None | | | | | | |
| Example | : | 16SAV | 16SAV Axis 16, save settings | | | | | |



(STA)

| Status Byte | | | | | | | | | | | | | |
|----------------|------------------|--|--|--|---|---|--|--------------------------------|----------|--|--|--|--|
| During | Motion | Rea | ll-time | Pro | gram | | | Global | | | | | |
| Set | Read | Set | Set Read Set Read Set Read | | | | | | | | | | |
| | \checkmark | | \checkmark | | | | | | | | | | |
| Comm Desc | nand ription: | This con axis. | This command is used to check the status register for a specified axis. | | | | | | | | | | |
| Returr | 15: | A read of the statu determine Bit Name Note: Bits 2 Bit 7: Bit 6: Bit 5: Bit 4: Bit 3: Bit 2: Bit 1: Bit 0: | operation will is of the axis ne the value 7 6 ERR AC a 1 and 0 are unuse 1 - One or more clear. - 0 - No Errors have - 1 - Currently in A - 0 - Not in Acceled - 1 - Currently in C - 0 - Not in Constant - 1 - Currently in I - 0 - Not in Deceled - 1 - Stage has stop - 0 - Stage is movid - 1 - A Program is - 0 - No program i - 1 - Positive Switt - 1 - Negative Switt - | I return an The byte i of each bit. 5 C CNST ad errors have occ ve occurred. Acceleration phase of Constant Veloc ant Velocity ph Deceleration phase of pped. (In Closed s currently runr s running tch is Activated ch is not Activated tch is Activated tc | integer must be 4 DEC urred. Us hase of mo f motion. ity phase of ase of mo hase of mo f motion. d Loop Sta Loop, Sta hing hated vated | from (decod 3 STP e ERR? (otion. of motion. tion. tion. | to 255 led in bi 2 PGM Or CER to n. | descril nary to 1 PLS | 0 NLS | | | | |
| Syntax | K: | nSTA? Error(s) | — Standard synt : STA? — Read nSTA — Miss | ax l operation with ing read operat | ı missing ion param | axis num eter [28] | ber [27] | | | | | | |
| Param Desc | eter ription: | n[int] ? | Axis number Read status re | egister | | | | | | | | | |
| Param Rang | eter ge: | n − 1 to | n - 1 to 99 | | | | | | | | | | |
| Relate Comm | ed nands: | None | None | | | | | | | | | | |
| Exam | ple: | 6STA? | | Axis 6, Re | ad status | register | | | | | | | |



STP

| Stop M | Stop Motion | | | | | | | | | | |
|----------------|--------------------|---------------|---|-----|------|--------------|------|--|--|--|--|
| During Motion | | Rea | ıl-time | Pro | gram | Global | | | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | | |
| \checkmark | | \checkmark | | | | \checkmark | | | | | |
| Comn Desc | nand cription: | This co | This command is used to stop motion for a specified axis. | | | | | | | | |
| Return | ns: | A read of | A read operation cannot be used with this command. | | | | | | | | |
| Synta | x: | nSTP 0STP- | nSTP – Standard syntax OSTP– All axes execute stop | | | | | | | | |
| Param Desc | neter cription: | n[int] – | - Axis number | | | | | | | | |
| Param Rang | neter ge: | n = 0 to | 99 | | | | | | | | |
| Relate Comm | ed nands: | EST, D | EST, DEC | | | | | | | | |
| Exam | ple: | 8STP | 8STP Axis 8, execute stop | | | | | | | | |



(SVP)

Save Startup Position

| During | Motion | Real-time | | Prog | gram | Global | |
|--|--------------|--|--|--|---|---|---|
| Set | Read | Set | Read | Set | Set Read | | Read |
| | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | |
| Comman Descrip | d tion: | This co 0. This into mo To reso | ommand is a setting doe emory. It al- et the Startu | used to set as not requ so does no p position | the startup ire the SAV t change w to the defa | position. / comman ith a DEF ult, send r | Default is d to save it command. SVP0. |
| Returns: A read operation returns the Startup position setting for the specified axis. | | | | | | | ng for the |
| Syntax: | | nSVP – Standard syntax OSVP – Missing axis number, command accepted as standard syntax | | | | | |
| Paramete Descrip | er tion: | n[int] x[float ? | Axis numb Startup Read Start | per Position m up Position | ım | | |
| Paramete Range: | r | n = 0 to x = TL |) 99 N (-999.999999 | 9mm) to TLP(| 999.999999mi | n) | |
| Related Comman | ds: | None | | | | | |
| Example | : | 4SVP Set current position to Startup position2SVP2.3 Set startup position to 2.3mm | | | | | |


(SYN)

| Sync | | | | | | | | | |
|-------------------------|-------------|------------------------------|---|-------------|--------------|-----------|--------|--|--|
| During | Motion | Rea | Real-time | | Program | | Global | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | | \checkmark | | | | | | |
| Command Description: | | This co for syn betwee | This command is used in a program together with the wait for sync [WSY] command in order to synchronize motion between multiple axes. | | | | | | |
| Returns: | | A read | operation c | cannot be u | used with th | nis comma | nd. | | |
| Syntax: | | nSYN 0SYN | nSYN – Standard syntax OSYN – Missing axis number, command accepted as standard syntax | | | | | | |
| Paramete Descrip | er tion: | n[int] — Axis number | | | | | | | |
| Paramete Range: | er | n - 0 to 99 | | | | | | | |
| Related Comman | ds: | WSY | | | | | | | |
| Example | : | 4SYN | 4SYN Send sync to axis 4 | | | | | | |



(TLN)

Negative Soft Limit Position

| During | Motion | Real-time | | Program | | Global | | | |
|---|--------------|--|--|---|-----------------|--------------|--|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark \checkmark \checkmark \checkmark | | | | | | |
| Command Description: This command is used to set the desired negative position, using absolute position, for the specifier negative soft limit position value must be less that positive soft limit position value [TLP] for the co- be accepted. | | | | | | | soft limit l axis. The n the mmand to | | |
| Returns: | | A read value. | operation r | eturns the | negative so | oft limit po | osition | | |
| Syntax: | | nTLNx nTLN? 0TLN× nTLN Error(s | nTLNx – Standard syntax nTLN? – Read negative soft limit position value OTLNx – All axes set limit position value nTLN – Set current position to negative limit Error(s): TLN? – Read operation with missing axis number [27] | | | | | | |
| Paramete Descript | er tion: | n[int] x[float] ? | — Axis numb — Negative s — Read nega | oer oft limit posit tive soft limit | ion position | | | | |
| Paramete Range: | er | n = 0 to x = -99 | 99 9.9999999 to TL | P mm [degree | es] | | | | |
| Related Comman | ds: | TLP | | | | | | | |
| Example | : | 2TLNC to 0.005 - 6TLN? - 1TLN | 2TLN0.005 Axis 2, Set negative soft limit p to 0.005 mm [degrees] - Axis 6, Read negative soft limit position value - Axis 1 Set the negative limit to the curren position | | | | | | |



TLP

Positive Soft limit Position

| During | Motion | Real-time | | Program | | Global | | | |
|---------------------|--------------|--|--|--|--|---|---|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | | |
| Comman Descrip | d tion: | This co positio positiv negativ be acce | ommand is o n, using abs e soft limit e soft limit epted. | used to set solute posi position v position v | the desired tion, for the alue must b alue [TLN | l positive s e specified be greater t] for the co | soft limit l axis. The han the ommand to | | |
| Returns: | | A read value f | operation r or the speci | eturns the fied axis. | positive so | ft limit po | sition | | |
| Syntax: | | nTLPx nTLP? 0TLPx nTLN Error(s | nTLPx – Standard syntax nTLP? – Read positive soft limit position value 0TLPx – All axes set limit position value nTLN – Set current position to negative limit Error(s): TLP? – Read operation with missing axis number [27] | | | | | | |
| Paramete Descrip | r tion: | n[int] x[float] ? | Axis numb Positive so Read posit | per oft limit positi ive soft limit | on position | | | | |
| Paramete Range: | r | n = 0 to x = TL | 99 N to + 999.999 | 999 mm [degi | ees] | | | | |
| Related Comman | ds: | TLN | | | | | | | |
| Example | : | 4TLP10.005 Axis 2, Set positive soft position to 10.005 - mm [degrees] 9TLP? Axis 9, Read positive soft limit position value - 1TLP 1TLP Axis 1 Set the positive limit to the current position | | | | | | | |



(TRA)

| Perform ' | Trace | | | | | | | | | |
|---------------------------|------------|---|---|---------|--|---|--|--|--|--|
| During | Motion | Real-time | | Program | | Gl | obal | | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | | |
| Comman Descrip | d tion: | This co axis. I TTL lo trigger | This command is used to execute a trace of the specified axis. In lieu of the trace beginning at value stored in x3, a TTL logic pulse to an IO pin [IOF] [IOD] can be used to trigger the trace function from an external source. | | | | | | | |
| Returns: | | A read specific | A read operation returns the position samples taken for the specified axis. | | | | | | | |
| Syntax: | | nTRA2 nTRA2 0TLPx Error(s | nTRAx1,x2,x3 — Standard syntax nTRA? — Read position values 0TLPx1,x2,x3 — All axes execute trace Error(s): TRA? — Read operation with missing axis number [27] nTRA — Missing parameters [28] | | | | | | | |
| Parameter Description: | | n[int]- Axis numberx1[int]- Number of samples taken (default is 1000)x2[int]- 10kHz /Sampling frequency (default is 1)x3[float]- Trace starting position (default is immediate)?- Read number of position samples collected | | | | | | | | |
| Paramete Range: | r | n - 0 $x1$ $x2$ $x3 - 00$ | $\begin{array}{ll} n & -0 \text{ to } 99 \\ x1 & -1 \text{ to } 9000 \\ x2 & -1 \text{ to } 1000 \text{ Servo clocks per cycle} \\ x3 & -000.000001 \text{ to } 999.999999 \text{ mm [degrees]} \end{array}$ | | | | | | | |
| Related Comman | ds: | DAT, I | OF, IOD | | | | | | | |
| Example: | | 5TRA5, 10, 1 samples at a at a 3TRA2000, , 2000 samples at starting at the | | | A sampling position o A a sampling current po | axis 5, execute frequency of 1 f 1 mm [degre axis 3, execute g frequency of sition | e trace with 5 kHz starting es] e trace with f 10kHz | | | |



VEL

| Velocity | | | | | | | | |
|---|--|--|-----------------------|--------------|-------------|---------------------------------------|-----------|--|
| During | Motion | Real-time | | Program | | Global | | |
| Set | Read | Set | Read | Set | Read | Set | Read | |
| \checkmark | \checkmark | \checkmark | \checkmark | \checkmark | | \checkmark | | |
| Command Description: This command is used to set the desired velocity for the specified axis. The velocity may be changed on-the-fly sending another VEL command during motion. The velocity value should be lower than the maximum allow velocity [VMX] for the command to be accepted. | | | | | | or the e-fly by ne allowable | | |
| Returns: | | A read op specified | peration ret axis. | urns the ve | elocity val | ue in mm/s | s for the | |
| Syntax: | | nVELx – Standard syntax nVEL? – Read velocity value 0VELx – Missing axis number, all axes set velocity Error [#]: VEL? – Read operation with missing axis number [27] nVEL – Missing velocity parameter [28] | | | | |] | |
| Parameter Descript | Parametern[int]- Axis numberDescription:x[float]- Velocity value?- Read velocity value | | | | | | | |
| Parameter Range: | r | n - 0 to 99 x - 000.001 to VMX (999.999 mm/s) [degrees/s] | | | | | | |
| Related Command | ds: | VMX, R | EZ | | | | | |
| Example: | | 1VEL.25 Axis 1, Set velocity to 0.25mm/s [degrees/s]-5VEL? Axis 5, Read velocity value | | | | | grees/s] | |



(VER)

Firmware Version

| During | Motion | Rea | l-time | Program | | Global | | | |
|---------------------|---|--------------------|--|------------|------|--------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | | √ | | | | | | |
| Comman Descrip | d tion: | This co specifi | This command is used to check the firmware version for the specified axis. | | | | | | |
| Returns: | | A read | A read operation returns the firmware version for the specified axis. | | | | | | |
| Syntax: | nVER? – Standard syntax Error(s): VER? – Read operation with missing axis number [27] nVER – Missing read operation parameter [28] | | | | | 27] | | | |
| Paramete Descrip | er tion: | n[int] - ? - | – Axis number – Read firmwa | re version | | | | | |
| Paramete Range: | er | n – 1 to 99 | | | | | | | |
| Related Comman | ds: | None | None | | | | | | |
| Example | : | 11VEF | 11VER? Axis 11, Read firmware version | | | | | | |





Maximum Allowable Velocity

| During Motion | | Rea | l-time | Program | | Global | | |
|-----------------------|---|---|-------------------------------|----------------|---------------------|------------|---------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | \checkmark | | \checkmark | | | | | |
| Comman Descript | d tion: | This command is used to read the maximum allowable velocity for a specific axis. This value is calculated based on the steps per micron parameter in the REZ command. | | | | | | |
| Returns: | | A read op value in | peration ret mm/s for th | urns the m | aximum a l axis. | llowable v | elocity | |
| Syntax: | nVMX? – Read maximum allowable velocity value Error [#]: VMX? – Read operation with missing axis number [27] nVMX – Missing read operation parameter [123] | | | | | 7] | | |
| Parameter Descript | r tion: | n[int] - ? - | – Axis number – Read maxim | um allowable v | velocity value | , | | |
| Parameter Range: | r | n — 1 to 99 | | | | | | |
| Related Commane | ds: | REZ, VEL | | | | | | |
| Example: | | 4VMX? Axis 4, Read maximum allowable velocity value | | | | | owable | |



VRT

| During | Motion | Rea | l-time | Prog | ram | Global | | | |
|--|--------------|---------------------|---|------|------|--------|------|--|--|
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | \checkmark | | \checkmark | | | | | | |
| Comman Descrip | d tion: | This co the enco | This command returns the actual velocity calculated from the encoder. | | | | | | |
| Returns: | | A read | A read operation returns the encoder velocity in mm/s. | | | | | | |
| nVRT? – Standard syntax Syntax: Error [#]: VRT? – Read operation with missing axis number [27] | | | | | 7] | | | | |
| Paramete Descrip | r tion: | n[int] | — Axis numb | er | | | | | |
| Paramete Range: | r | n - 1 to 99 | | | | | | | |
| Related Comman | ds: | POS | POS | | | | | | |
| Example | : | 5VRT? | 5VRT? Axis 5, Read encoder velocity | | | | | | |



WST

Parameter

Range:

Related

Commands:

Example:

| Wait For | Stop | | | | | | | | |
|--|---|--|--|--------------|---------|-----------|--------|--|--|
| During Motion | | Rea | l-time | Pro | Program | | Global | | |
| Set | Read | Set | Read | Set | Read | Set | Read | | |
| | | | | \checkmark | | | | | |
| Comman Descrip | d tion: | This command is used in a program to wait until motio completed to begin executing the next command. | | | | notion is | | | |
| Returns: | | A read | A read operation cannot be used with this command. | | | | | | |
| Syntax: | : MWST – Standard syntax WST – Missing axis number, command accepted a syntax | | | as standard | | | | | |
| Parameter Description: n[int] – Axis number | | | | | | | | | |

n - 1 to 99

PGM

7WST



Axis 7, Wait for motion to stop before

executing next command

(WSY)

| Wait For Sync | | | | | | | | |
|--|--------------|---|---------------|----------------|------|--------------|---------------------|--|
| During Motion | | Real-time | | Program | | Global | | |
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | | | \checkmark | | \checkmark | | |
| Comman Descrip | nd ation: | This command is used in a program together with the [SYN] command in order to synchronize motion betwe multiple axes. | | | | | the sync between | |
| Returns: | | A read operation cannot be used with this command. | | | | nd. | | |
| Syntax: nWSY — Standard syntax WSY — Missing axis number, command accep | | | nmand accepte | ed as standard | | | | |

| Syntax: | nWSY — Standard syntax WSY — Missing axis number, command acc syntax | epted as standard |
|---------------------------|--|--------------------------------------|
| Parameter Description: | n[int] – Axis number | |
| Parameter Range: | n - 1 to 99 | |
| Related Commands: | SYN | |
| Example: | 1WSY Axis 1, Wait unti received before command | il sync command is executing next |



(WTM)

Wait For Time Period

| During Motion | | Rea | Real-time | | Program | | Global | |
|---------------------------|------|----------------------|---|--------------|------------------------------|-------------------------------|-------------|--|
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | | | \checkmark | | | | |
| Command Description: | | This co period | This command is used in a program to wait for a specified period of time before executing the next command. | | | | | |
| Returns: | | A read | A read operation cannot be used with this command. | | | | | |
| Syntax: | | nWTM WSTx | nWTMx – Standard syntax WSTx – Missing axis number, command accepted as standard syntax | | | | | |
| Parameter Description: | | n[int] x[int] | n[int] – Axis number x[int] – Time | | | | | |
| Parameter Range: | | n - 1 to x - 0 to | n − 1 to 99 x − 0 to 999999 milliseconds | | | | | |
| Related Commands: | | PGM | | | | | | |
| Example | : | 2WTM4 | 12 | Axis 2 | , Wait for 42 n executing | nilliseconds b next commar | efore Id | |



ZRO

| Zero Position | | | | | | | | |
|---------------------------|------|----------------------|--|--------------|------------------|-----------------|------------|--|
| During Motion | | Real-time | | Program | | Global | | |
| Set | Read | Set | Read | Set | Read | Set | Read | |
| | | \checkmark | | \checkmark | | \checkmark | | |
| Command Description: | | This co the spe | This command is used to set the absolute zero position for the specified axis. | | | | | |
| Returns: | | A read | A read operation cannot be used with this command. | | | | | |
| Syntax: | | nZRO Error [Z | nZRO – Standard syntax Error [#]: ZRO – Missing axis number [123] | | | | | |
| Parameter Description: | | n[int] | n[int] — Axis number | | | | | |
| Parameter Range: | | n - 1 to 99 | | | | | | |
| Related Comman | ds: | None | | | | | | |
| Example | : | 1ZRO | | Axis 1 | , set current po | osition as abso | olute zero | |



Error Messages

| Error Number | Name | Description |
|-----------------|----------------------------------|--|
| 10 | Receive Buffer Overrun | The Receive Buffer has reached or exceeded maximum capacity. |
| 11 | Motor Disabled | The command that triggered this error was trying to move the servo while it was disabled. |
| 12 | No Encoder Detected | The command that triggered this error was trying to access encoder data when no encoder was attached. |
| 13 | Index Not Found | The controller moved across the full range of motion and did not find an index. |
| 14 | Home Requires Encoder | The HOM command requires an encoder signal. |
| 15 | Move Limit Requires Encoder | The MLN and MLP commands require an encoder signal. |
| 20 | Command is Read Only | The command that triggered this error only supports read operations. The command must be followed by a question mark to be accepted. Ex: XXX? |
| 21 | One Read Operation Per Line | Multiple read operations on the same command line. Only one read operation is allowed per line, even if addressed to separate axes. |
| 22 | Too Many Commands On Line | The maximum number of allowed commands per command line has been exceeded. No more than 8 commands are allowed on a single command line. |
| 23 | Line Character Limit Exceeded | The maximum number of characters per command line has been exceeded. Each line has an 80 character limit. |
| 24 | Missing Axis Number | The controller could not find an axis number or the beginning of an instruction. Check the beginning of the command for erroneous characters. |
| 25 | Malformed Command | The controller could not find a 3-letter instruction in the input. Check to ensure that each instruction in the line has exactly 3 letters referring to a command. |



| 26 | Invalid Command | The 3-letter instruction entered is not a valid command. Ensure that the 3-letter instruction is a recognizable command. |
|----|---|--|
| 27 | Global Read Operation Request | A read request for a command was entered without an axis number. A read request cannot be used in a global context. |
| 28 | Invalid Parameter Type | The parameter entered does not correspond to the type of number that the instruction requires. For example, the command may expect an integer value, therefore sending a floating point value will trigger this error. The allowable precision for a parameter has been exceeded. For example, velocity can be specified with a precision of 0.001 mm/sec. If a more precise velocity value of 0.0001 mm/sec is entered, this error will be triggered. Refer to the command pages for the type of parameter that each command expects. |
| 29 | Invalid Character in Parameter | There is an alpha character in a parameter that should be a numeric character. |
| 30 | Command Cannot Be Used In Global Context | The command entered must be addressed to a specific axis number. Not all commands can be used in a global context. Check the specific command page or the table of commands for more info. |
| 31 | Parameter Out Of Bounds | The parameter is out of bounds. The current state of the controller will not allow this parameter to be used. Check the command page for more information. |
| 32 | Incorrect Jog Velocity Request | The jog velocity can only be changed during motion by using a new JOG command. If the VEL command is used to change the velocity, this error will be triggered. The VEL command can only be used to change velocity during motion initiated by the move commands [MVR, MVA, MSR, MSA]. |
| 33 | Not In Jog Mode | Sending a JOG command during motion initiated by a move command will trigger this error. To initiate Jog Mode, the controller should be at stand-still. To change velocity during a move, use the VEL command. |
| 34 | Trace Already In Progress | This error is triggered when a new trace command is received after a trace is already in progress. Trace settings may be modified only if the trace hasn't started recording data. Otherwise, wait until the trace has finished before modifying the trace settings. |
| 35 | Trace Did Not Complete | An error occurred while recording trace data. Try the operation again. |



| 36 | Command Cannot Be Executed During Motion | Only certain commands can be executed when motion is in progress. Check the command pages for information on individual commands. |
|----|--|--|
| 37 | Move Outside Soft Limits | If a requested move will take the controller outside of the preset travel limits, then the command will not be executed. |
| 38 | Read Not Available For This Command | This error is triggered by a read request from a command that does not support a read operation. |
| 39 | Program Number Out of Range | The number entered for the program number was either less than 1 or greater than 16. |
| 40 | Program Size Limit Exceeded | The program has exceeded the character limit of 4 Kb. |
| 41 | Program failed to Record | Error in recording program. Erase program and try operation again. |
| 42 | End Command Must Be on its Own Line | The End command used to end a program must be on a separate line from all other instructions. |
| 43 | Failed to Read Program | An error occurred while trying to read a program. Try the Operation again. |
| 44 | Command Only Valid Within Program | The command that triggered this error is only suitable for use within a program. |
| 45 | Program Already Exists | A program already exists for the indicated program parameter. The program must be erased with the ERA command before being written again. |
| 46 | Program Doesn't Exist | The indicated program does not exist. This error can occur when you try to execute a program number that has not had a program assigned to it. |
| 47 | Read Operations Not Allowed Inside Program | Read Operations are not permitted in programs. |
| 48 | Command Not Allowed While Program in Progress | The command that triggered this error was given while a program was executing. |
| 50 | Limit Activated | Motion in the direction of the activated limit switch is disallowed if limit switches are enabled. |



| 51 | End of Travel Limit | The requested move will take the controller outside of its valid travel range, therefore the move is disallowed. |
|----|---|--|
| 52 | Home In Progress | A Home or a Move To Limit Procedure is in progress. Motion commands are disallowed during this time. A STP or EST command can be used to terminate the Home, and then a motion command can be sent. |
| 53 | IO Function Already In Use | The I/O Function in question is already assigned to another I/O pin. Some Functions can only be assigned to one pin at a time. See the documentation for each function for more details. |
| 55 | Limits Are Not Configured Properly | Both Limit Switches are active, so motion is disallowed in both directions. Most likely the LPL (Limit Polarity command) setting should be switched. |
| 80 | Command Not Available in this Version | The command entered is not supported in this version of the firmware. |
| 81 | Analog Encoder Not Available In this Version | The current version of firmware installed does not support Analog Encoders. |



8. Pin Outs

8.1.1 Power Pin-Out

| Pin | Description |
|-----|-------------|
| 1 | +24V |
| 2 | GND |

8.1.2 Motor/Encoder Pin-Out

| Pin | Description |
|-----|----------------|
| 1 | Motor Phase 1 |
| 2 | Motor Phase 2 |
| 3 | N/C |
| 4 | N/C |
| 5 | Motor GND |
| 6 | Limit Switch + |
| 7 | Limit Switch - |
| 8 | A+ |
| 9 | B+ |
| 10 | Index+ |
| 11 | +5V |
| 12 | Signal GND |
| 13 | A- |
| 14 | В- |
| 15 | Index- |

8.1.3 RS-485 Input

| Pin | Description |
|-----|-------------|
| 1 | +24VDC |
| 2 | 24V GND |
| 3 | RS485 A |
| 4 | RS485 B |
| 5 | ID In |
| 6 | RS485 GND |

8.1.4 RS-485 Output

| Pin | Description |
|-----|-------------|
| 1 | +24VDC |
| 2 | 24V GND |
| 3 | RS485 A |
| 4 | RS485 B |
| 5 | ID Out |
| 6 | RS485 GND |



